

IOMOD FPI User Manual

1. Introduction

IOMod FPI stands for Fault Passage Indicator. It is an intelligent electronic device (IED) used for short circuit and ground fault indication with direction detection. It measures three phases of AC voltage and current amplitudes and phase shifts. The faults are detected by applying certain algorithms along with the measured data. The measured and calculated values are transmitted to the host system via communication protocol **Modbus RTU, IEC 60870-5-101 or IEC 60870-5-103**.

1.1 Features

- Directional fault detection for all network types;
- Earth fault detection;
- 50 Instantaneous overcurrent detection;
- 50N Neutral instantaneous overcurrent detection;
- 51/67 Phase directional overcurrent detection;
- 67N Neutral directional overcurrent detection;
- 27 Undervoltage detection (with VT or voltage sensors);
- 59 Overvoltage detection (with VT or voltage sensors);
- 59N Neutral overvoltage detection / permanent earth fault (with VT or voltage sensors);
- 81HBL2 Inrush blocking for selected protections;
- **2 settings groups;**
- Integration into Elseta mini RTU;
- Measurements of RMS values for currents, phase, and phase-to-phase voltages.
- Additional measurements of:
 - Frequency;
 - Active, reactive, and apparent power;
 - Neutral voltage, neutral current;
 - Power factor;
 - Phase angle;
- Analog inputs measurement in 16-bit resolution;
- 3x low-power (LoPo) current measuring inputs (225 mV) or 3 x 1 A/5 A CT with the adapter;
- 3x low-power (LoPo) voltage measuring inputs (3.25 V/ $\sqrt{3}$) or 3 x 100 V/400 V VT with the adapter;
- Frequency acquisition (Nominal frequencies: 50 and 60 Hz; Frequency range: 45–65 Hz);
- Firmware upgrade over USB, RS485;
- Configurable using the IOMOD Utility app for user-friendly setup;
- RS485 interface with a switchable terminating resistor;
- Compact case with a removable transparent front panel;
- DIN rail mounting for seamless integration into industrial systems.

1.2 Block diagram




Fig. 1.2.1 IOMOD FPI internal structure and block diagram

2. Hardware data

2.1 Mechanical drawings




Fig. 2.1.1 IOMod FPI side view with dimensions and terminals description. 1 - first channel three phase current inputs; 2 - three phase voltage (second channel current) inputs; 3 - four digital outputs; 4 - ground input for analogue measurements; 5 - RS485 interface; 6 - power supply input




Fig. 2.1.2 IOMod FPI front view with dimensions

2.2 Terminal connections

IOMod FPI has 22 terminals, which are depicted below:



Fig. 2.2.1 IOMod FPI terminal diagram

The description of each terminal can be found in the table below:

Table 2.2.1 Terminal Specifications

Terminal number	Terminal name	Description
1	Ia	Phase current 1
2	N	
3	Ib	Phase current 2 or neutral current in case of I_0 metered mode
4	N	
5	Ic	Phase current 3
6	N	
7	Ua	Phase voltage 1 or phase current 1 in case of 3I3I connection mode
8	N	
9	Ub	Phase voltage 2 or phase current 2 in case of 3I3I connection mode, or neutral current in case of 3I3I connection mode along with I_0 metered mode
10	N	
11	Uc	Phase voltage 3 or phase current 3 in case of 3I3I connection mode
12	N	
13	O1.1	Digital output 1
14	O1.2	
15	O2.1	Digital output 2
16	O2.2	
17	COM	Analogue measurements common neutral terminals
18	COM	
19	A	RS485 interface port
20	B	

21	V-	Power source inputs
22	V+	

2.3 Status indication

IOMod FPI has six LEDs (Fig 2.3.1), which are used to indicate the fault detection, communication and power statuses.



Fig. 2.3.1 IOMod FPI LEDs physical location

The description of each IOMod FPI LED can be found in the table below:

Table 2.3.1 Description of LEDs.

Name	LED color	Description
I>	□ (green)	The current level of all channel inputs is acceptable
	□ (red)	Overcurrent is detected in one or more current lines. The LED indication is active only if one of the current fault detection functions (50, 51, 67) is activated
I ₀ >	□ (green)	The neutral current level is acceptable.
	□ (red)	Neutral current line earth fault is detected in either A or B direction. The LED indication is active only if one of the neutral current fault detection functions (50N, 51N, 67N) is activated.
O1	□ (green)	Digital output is tripped.
	□ (red)	Digital output is closed. The output closing can be triggered by: <ol style="list-style-type: none"> 1. Overcurrent; 2. A fault in the first channel (in case of 3I3I connection mode); 3. A fault in A direction (in case of function 67).
O2	□ (green)	Digital output is tripped.
	□ (red)	Digital output is closed. The output closing can be triggered by: <ol style="list-style-type: none"> 1. Earth fault; 2. A fault in the second channel (in case of 3I3I connection mode); 3. A fault in B direction (in case of function 67).
RX/TX	□ (green)	Blinking green light indicates active communication via RS485 interface.

STAT	□ (green)	Power source is connected to the power supply input.
	□ (blue)	IOMod FPI is connected to an external device via USB mini cable.

3. Technical information

Table 3.1 Technical specifications.

System		
Dimension	17.5 (H) x 101 (W) x 119 (L), mm	
Case	ABS, black	
Working environment	Indoor	
Operating temperature	-40°C ... +85°C	
Recommended operating conditions	5–60°C and 20–80% RH	
Configuration	USB, RS485	
Firmware upgrade	USB, RS485	
Electrical specifications		
Inputs	Resolution	16 bits
	Input resistance	~1 MΩ
	Input capacitance	< 170 pF
	Input ranges	±10 V (amplitude)
	Nominal values	Current input: 225 mV (RMS) Voltage input: 1.876 V (RMS)
	Overvoltage protection for all inputs	up to ±20 V
Outputs	On-Resistance (max)	16 Ω
Power		
Power Supply	9–33 VDC (full range)	
Current consumption	40 mA @ 12 VDC, 20 mA @ 24 VDC	

4. Mounting and installation

4.1 Connection Diagrams

In this chapter the various options of connecting the device to medium-voltage systems are discussed.

4.1.1 3 Low-Power Current Sensor, 3 Low-Power Voltage Sensors

In the case of 3I3U connection mode IOMod FPI can be connected to a medium-voltage system by using low-power current and low-power voltage sensors (Fig. 4.1.1.1). In this scenario the neutral current I_0 and the neutral voltage U_0 are calculated by taking a vector sum of appropriate measurements. IOMod FPI GND inputs are not required to be connected to the neutral line because they are interconnected with signal neutral inputs (Fig. 1.2.1). As far as voltage measurements are taken along with current measurements directional information can be provided in case of a fault.




Fig. 4.1.1.1 Connection diagram with 3 low-power current and 3 low-power voltage sensors

4.1.2 Fault Passage Indicator for a single feeder

IOMod FPI can perform fault passage indication with only its current inputs connected to a single feeder of a medium-voltage system (Fig. 4.1.2.1). In the scheme below IOMod FPI current inputs are connected to a feeder via low-power current sensors. However, this connection scheme restricts IOMod FPI fault detection capabilities only to the current related faults. Also, the absence of voltage measurements results in inability to provide the directional fault information.




Fig. 4.1.2.1 IOMod FPI connection diagram for a single feeder

4.1.3 Fault Passage Indicator for two feeders

The special feature of IOMod FPI is the ability to be used as a fault passage indicator for two feeders (Fig 4.1.3.1). In this case 3I3I connection mode needs to be enabled in IOMod Utility (Fig. 4.1.3.2).




Fig. 4.1.3.1 IOMod FPI connection diagram for two feeders




Fig. 4.1.3.2 IOMod Utility General settings tab with Connection mode set to 3I3I

This mode allows us to use IOMod FPI voltage inputs for current measurements, so that the currents of both feeders are measured simultaneously. In the connection scheme above (Fig. 4.1.3.1) IOMod FPI current inputs are connected to the pair of feeders via low-power current sensors. Similarly to the previous example, the absence of voltage measurements results in inability to provide the directional fault information. Besides, this connection scheme restricts IOMod FPI fault detection capabilities only to the current related faults.

4.1.4 3 Low-Power Voltage Sensor, 2 Phase Current, and Core Balance Current Transformer

IOMod FPI allows directly measure the neutral current. In order to use this feature I_0 current acquiring mode needs to be switched in IOMod Utility from calculated to metered (Fig. 4.1.4.1).




Fig. 4.1.4.1 IOMod Utility 3I3U settings view with I_0 mode switched to metered

After enabling I_0 metered mode IOMod FPI second phase input (Ib+/N) becomes neutral current input. Since neutral current measurements are performed directly instead of being calculated it allows to achieve much higher precision and sensitivity. While neutral current being metered directly, the second phase measurements are being calculated by taking a vector sum of the measured currents. In the scheme below (Fig. 4.1.4.2) current and voltage measurements

are taken by using low-power current and low-power voltage sensors. The second input (Ib+/N) is connected to a low-power current sensor which is placed on the neutral line.




Fig. 4.1.4.2 IOMod FPI I_0 metered mode connection diagram

4.1.5 2 Phase Current, and Core Balance Current Transformer

Similarly to I_0 calculated mode IOMod FPI can take solely current measurements via low-power current sensors (Fig. 4.1.5.1). However, this connection scheme restricts IOMod FPI fault detection capabilities only to the current related faults. Also, the absence of voltage measurements results in inability to provide the directional fault information.




Fig. 4.1.5.1 IOMod FPI I_0 metered mode connection diagram without voltage measurements

4.1.6 2 Phase Current, and Core Balance Current Transformer for two feeders

IOMod FPI operating in I_0 metered mode preserves the ability of monitoring the currents of two feeders (Fig. 4.1.6.1). In this case 3I3I connection mode needs to be enabled in IOMod Utility (Fig. 4.1.3.2). 3I3I connection mode allows using voltage inputs as second channel current inputs.




Fig. 4.1.6.1 IOMod FPI connection diagram for two feeders with both channels I_0 metered mode

In the connection scheme above (Fig. 4.1.6.1) IOMod FPI current inputs are connected to the pair of feeders via low-power current sensors. It should be noted that the absence of voltage measurements results in an inability to provide the directional fault information. Besides, this connection scheme restricts IOMod FPI fault detection capabilities only to the current related faults.

Moreover, in IOMod Utility I_0 mode of both current input channels needs to be changed from calculated to metered (Fig. 4.1.6.2).

General info	Communication settings	Iomod settings	Diagnostics
General	3I3I	Protection CH1	Protection CH2
Data select			
Primary current ch1 (A)			100
Primary current ch2 (A)			100
Current sensor ch1 (mV)			225
Current sensor ch2 (mV)			225
I0 mode ch1			metered
I0 mode ch2			metered
Primary current I0 ch1			100
Primary current I0 ch2			100

Fig. 4.1.6.2 IOMod Utility 3I3I settings view with I_0 mode of both channels set to metered

4.1.7 Conventional Current transformers (CT) connection via CT adapters.

IOMod FPI can take current measurements via a current transformer adapter (Fig. 4.1.7.1). Contrary to the current sensors, current transformers are usually intended for transforming priorly lowered currents from secondary distribution networks.




Fig. 4.1.7.1 IOMod FPI connection diagram with current transformer adapter and low-power voltage sensors

4.1.8 Conventional Voltage transformers (VT) connection via VT adapters.

IOMod FPI is able to take voltage measurements via a voltage transformer adapter (Fig. 4.1.7.1). Contrary to the voltage sensors, voltage transformers are usually intended for transforming priorly lowered voltages from secondary distribution networks.




Fig. 4.1.8.1 IOMod FPI connection diagram with low-power current sensors and voltage transformer adapter

4.2 Digital outputs

IOMod FPI has two digital outputs which are based on Solid State Relays (SSR). Since SSR's are in use an additional up to 16 Ω on-resistance is introduced. Operation logic of digital outputs is predetermined and cannot be controlled or configured via IOMod Utility. The operation of a digital output is triggered when a certain fault is detected (Table 4.2.1). The statuses of both digital outputs are indicated by two LED's (Table 2.3.1).

Table 4.2.1 Digital outputs activation conditions.

Output Number	Activation Conditions
1	Over current in the first channel (in case of 50 and 51 detection functions)
	Over current in A direction (in case of function 67)
2	Over current in the second channel (in case of 50 and 51 detection functions and 3I3I connection mode)
	Over current in B direction (in case of function 67)

In the scheme below an application example of IOMod FPI digital outputs with another device is displayed (Fig. 4.2.1). For the sake of the example IOMod 8DI4RO was selected as a device for receiving digital signals from IOMod FPI. The first terminal of both digital outputs O1.1 and O2.1 are connected to a common external voltage source. The second terminal of the first digital output O1.2 is connected to IOMod 8DI4RO seventh digital input IN7. The second terminal of the second digital output O2.2 is connected to IOMod 8DI4RO sixth digital input IN6. The negative terminal of the voltage source is connected to IOMod 8DI4RO input ground terminal. The digital output is activated when one of the relays becomes closed. It closes the previously described circuit as well.




Fig. 4.2.1 Digital outputs usage block diagram example with IOMod 8DI4RO

4.3 RS485 Interface

IOMod 4Cs4Vs has an integrated 120 Ω termination resistor, which can be enabled or disabled via the configuration terminal. It is recommended to use termination at each end of the RS485 cable.

IOMod FPI has a 1/8 Unit load receiver which allows having up to 255 units on a single line (compared to the standard 32 units). To reduce reflections, keep the stubs (cable distance from the main RS485 bus line) as short as possible.

4.4 Power supply

IOMod FPI needs to be powered by a 9–33 V power source. IOMod FPI power supply inputs are located next to RS485 interface inputs (Fig 4.4.1).



Fig. 4.4.1 Power supply inputs physical location

4.5 USB connection

IOMod FPI device has USB-mini connection port. Its primary function is physical connection establishment between the IOMod and a PC. By selecting USB interface and correct communication port in IOMod Utility (Fig. 4.5.1) a user can

connect to the IOMod to control its parameters and monitor its measured data and the status of fault detection functions. Also, this connection can be used for powering the module.




Fig. 4.5.1 IOMod Utility interface and communication port parameters



Fig. 4.5.2 IOMod FPI USB connection port physical location

5. Parametrization

In this section IOMod FPI settings configuration is described. IOMod FPI configuration is performed via IOMod Utility (the manual can be accessed [here](#)). All IOMod-related settings can be found in "IOMod settings" tab (Fig. 5.1).




Fig. 5.1 IOMod settings tab

5.1 General parameters

In order to configure IOMod FPI general settings open "IOMod settings" tab in IOMod Utility. After clicking on "IOMod settings", "General" section opens (Fig. 5.1.1).




Fig. 5.1.1 IOMod Utility with IOMod FPI general settings window opened

The general settings consist of six parameters, which apply for all communication protocols (Table 5.1.1). "Measurands set" and "Scale factor" are defined only in the context of IEC 60870-5-103 communication protocol. The last parameter "Value update time (ms)" is defined only in the context of IEC 60870-5-101 and IEC 60870-5-103 communication protocols.

Table 5.1.1 IOMod FPI general parameter ranges and default values.

Parameter	Range	Default value
Connection mode	3I3U, 3I3I	3I3U
Frequency	50 Hz, 60 Hz	50 Hz
Grounding	Solid, Isolated, Resonant	Solid
Active settings group	Group 1, Group 2	Group 1
Group 1 auto reset time (s)	1-60000	1800
Group 2 auto reset time (s)	1-60000	1800
Measurands set*	1-4 or 1-3**	1
Scale factor*	1.2, 2.4	1.2
Value update time (ms)***	20-60000	500

* The parameters are defined only for IEC 60870-5-103 communication protocol.

** In 3I3I connection mode only first three (1-3) measurands sets are available.

*** The parameter is defined only for IEC 60870-5-101 and IEC 60870-5-103 communication protocols.

The first parameter is "Connection mode" allows to define how the values measured with voltage inputs (terminals 7-12, see Fig. 2.2.1) are supposed to be interpreted. The values are interpreted as voltage measurements by default. This connection mode is denoted by 3I3U designation. 3I3U designation basically means - "three currents and three voltages" meaning that both current and voltage measurements are being taken from a feeder (see Fig. 4.1.1.1 as an example). 3I3U connection mode parameters can be found in a separate settings section which is labeled with communication mode designation (connection mode settings are described in the next section).




Fig. 5.1.2 IOMod Utility IOMod settings sections in 3I3I connection mode

Selecting 3I3I connection mode in IOMod Utility changes IOMod Setting sections (Fig. 5.1.2) - 3I3U changes to 3I3I and Protection section divides into two sections for each channel. IOMod FPI, in 3I3I connection mode, interprets the values measured with voltage inputs (terminals 7-12, see Fig. 2.2.1) as current measurements. 3I3I designation basically means - "three currents and three currents" meaning that the voltage inputs become the second channel current inputs (see Fig. 4.1.3.1 as an example). 3I3I settings section allows us to modify connection mode parameters (described in the next section). Protection CH1 and Protection CH2 store the fault detection function parameters of the first and second current channel respectively.

"Frequency" parameter allows us to set the nominal frequency of the power line to which IOMod FPI is connected to.

"Grounding" parameter sets one of the high-voltage earthing types. The selected earthing type influences the way a fault direction is determined. Also, earthing type effects phase angle calculation.

"Active settings group" allows us to select between two fault detection configuration groups. Two groups allow us to

save in IOMod FPI two separate fault detection configurations. The group division can be found in the related to Protection configuration setting sections (Fig. 5.1.3).

Fig. 5.1.3 IOMod Utility Protection function configuration group division

"Group 1 auto reset time (s)" and "Group 2 auto reset time (s)" parameters for each group respectively defines the time after which fault detection statuses are going to be reset automatically. The time period has to be provided in seconds.

If IEC 60870-5-103 communication protocol is selected, "Measurands set" parameter sets one of the lists of measurements (Table 7.3.2, Table 7.3.3) which is going to be sent to a master device.

If IEC 60870-5-103 communication protocol is selected, the "Scale factor" parameter sets a value by which all measurements are going to be multiplied.

Value update time (ms) parameter defines how frequently the updated values are going to be sent to a controlling station via IEC 60870-5-101 or IEC 60870-5-103 communication protocols.

5.2 Connection mode settings

As was described early IOMod FPI supports two connection modes – 3I3U and 3I3I. After selecting one of them in General settings (Fig. 5.1.1) a new respectively named section appears (Fig. 5.1.1, Fig.5.1.2). In this subsection the parameters of a certain connection mode are going to be described.

5.2.1 3I3U connection mode parameters

3I3U connection mode parameters section has eight parameters (Table 5.2), which are going to be described below.

Table 5.2 3I3U connection mode parameters.

Parameter	Range	Default value
Primary current (A)	1–2000	100
Primary voltage (kV)	0.2–60.0	10.0
Current sensor (mV)	100–300	225
Voltage sensor (V)	1.0–3.0	1.876
DO function	Direction, Fault type	Direction
I0 mode	Calculated, Metered	Calculated
Primary current I0	1–2000	100
Energy calculation enable	Enabled / Disabled	Disabled

- The "Primary current (A)" parameter defines the nominal input current of a current sensor or a current transformer.
- The "Primary voltage (kV)" parameter sets the nominal input line voltage of a voltage sensor or a voltage

transformer. If instead of the line voltage, the sensor or adapter converts the phase voltage, still the value of the line voltage must be used. For example, if a voltage sensor declares the primary voltage of $10/\sqrt{3}$ kV, then 10 kV must be used for "Primary voltage (kV)" parameter, for it is the line voltage of the network.

- The "Current sensor (mV)" parameter defines the nominal output voltage of a current sensor or a current transformer.
- The "Voltage sensor (V)" parameter defines the nominal output phase voltage of a voltage sensor or a voltage transformer. Contrary to the Primary Voltage, the phase voltage must be used for this parameter. For example, if a voltage sensor declares the secondary voltage of $3.25/\sqrt{3}$ V, then the approximate phase voltage value must be used. It means, that the given expression must be evaluated ($3.25/\sqrt{3} \approx 1.876$ V) and the result must be entered into the "Voltage sensor (V)" parameter (1.876 V).
- The "DO function" parameter defines the activation conditions of the digital outputs. Digital outputs are going to identify the direction of an overcurrent fault, i.e. A or B, if the parameter value is set to "Direction". In case of "Fault type" parameter value, the digital outputs are going to identify whether overcurrent or earth fault was detected.
- The "I0 mode" parameter defines the way of obtaining the neutral current values. The default parameter value is "Calculated", meaning that the value of the neutral current is going to be calculated by taking the phase current measurements. If "Metered" is selected, then the neutral current values are expected to be measured directly (e.g. Fig. 4.1.4.2).
- The "Primary current I0" parameter defines the nominal input neutral current which is being measured by a Core Balance Current Transformer.
- The "Energy calculation enable" parameter is disabled by default, meaning that the energy calculations are not going to be saved. Although, even when the parameter is disabled, energy indicator values are going to grow as far as IOMod FPI is connected to a functioning feeder, these values are not going to be saved in EEPROM memory. It means that the moment when IOMod FPI is disconnected from a power source, the energy measurements are lost. Enabling the parameter ensures that the energy measurements are written to EEPROM memory.

5.2.2 3I3I connection mode parameters

3I3I connection mode parameters section has eight parameters (Table 5.3), which are going to be described below.

Table 5.3 3I3I connection mode parameters.

Parameter	Range	Default value
Primary current ch1 (A)	1-2000	100
Primary current ch2 (A)	1-2000	100
Current sensor ch1 (mV)	100-300	225
Current sensor ch2 (mV)	100-300	225
I0 mode ch1	Calculated, Metered	Calculated
I0 mode ch2	Calculated, Metered	Calculated
Primary current I0 ch1	1-2000	100
Primary current I0 ch2	1-2000	100

- The "Primary current ch1 (A)" parameter sets the nominal input current of a current sensor or a current transformer which is connected to the first channel current inputs.
- The "Primary current ch2 (A)" parameter sets the nominal input current of a current sensor or a current transformer which is connected to the second channel current inputs.
- The "Current sensor ch1 (mV)" parameter defines the nominal output voltage of a current sensor or a current transformer which is connected to the first channel current inputs.
- The "Current sensor ch2 (mV)" parameter defines the nominal output voltage of a current sensor or a current transformer which is connected to the second channel current inputs.
- The "I0 mode ch1" parameter defines the way of obtaining the neutral current values with the first channel current inputs. The default parameter value is "Calculated", meaning that the value of the neutral current is going to be calculated by taking the phase current measurements. If "Metered" is selected, then the neutral current values are expected to be measured directly (e.g. Fig. 4.1.4.2).
- The "I0 mode ch2" parameter defines the way of obtaining the neutral current values with the second channel current inputs. The default parameter value is "Calculated", meaning that the value of the neutral current is going to be calculated by taking the phase current measurements. If "Metered" is selected, then the neutral current values are expected to be measured directly (e.g. Fig. 4.1.4.2).
- The "Primary current I0 ch1" parameter defines the nominal input neutral current which is being measured by a Core Balance Current Transformer connected to the first channel current inputs.
- The "Primary current I0 ch2" parameter defines the nominal input neutral current which is being measured by a Core Balance Current Transformer connected to the second channel current inputs.

5.3 Data select

Data select tab (Fig. 5.3.1) is the last IOMod settings section, which provides a way to control the data being sent via IEC 60870-5-101 communication protocol. The IOA (Information Object Address) of each data unit is specified in the brackets to the right of a parameter's name. In order to include a parameter to a set of parameters which are sent via IEC 60870-5-101 communication protocol a checkbox to the right of a parameter's name needs to be checked.

General info		Communication settings		Iomod settings		Diagnostics			
General	3I3U	Detection	Data select						
I1 (100)	<input checked="" type="checkbox"/>	I2 (101)	<input checked="" type="checkbox"/>	I3 (102)	<input checked="" type="checkbox"/>	I0 (103)	<input checked="" type="checkbox"/>	U1 (104)	<input checked="" type="checkbox"/>
U2 (105)	<input checked="" type="checkbox"/>	U3 (106)	<input checked="" type="checkbox"/>	U0 (107)	<input checked="" type="checkbox"/>	U12 (108)	<input checked="" type="checkbox"/>	U23 (109)	<input checked="" type="checkbox"/>
U31 (110)	<input checked="" type="checkbox"/>	P1 (111)	<input checked="" type="checkbox"/>	P2 (112)	<input checked="" type="checkbox"/>	P3 (113)	<input checked="" type="checkbox"/>	P (114)	<input checked="" type="checkbox"/>
Q1 (115)	<input checked="" type="checkbox"/>	Q2 (116)	<input checked="" type="checkbox"/>	Q3 (117)	<input checked="" type="checkbox"/>	Q (118)	<input checked="" type="checkbox"/>	S1 (119)	<input checked="" type="checkbox"/>
S2 (120)	<input checked="" type="checkbox"/>	S3 (121)	<input checked="" type="checkbox"/>	S (122)	<input checked="" type="checkbox"/>	PF1 (123)	<input checked="" type="checkbox"/>	PF2 (124)	<input checked="" type="checkbox"/>
PF3 (125)	<input checked="" type="checkbox"/>	PF (126)	<input checked="" type="checkbox"/>	Freq (127)	<input checked="" type="checkbox"/>	I1 angle (128)	<input type="checkbox"/>	I2 angle (129)	<input type="checkbox"/>
I3 angle (130)	<input type="checkbox"/>	I0 angle (131)	<input type="checkbox"/>	U1 angle (132)	<input type="checkbox"/>	U2 angle (133)	<input type="checkbox"/>	U3 angle (134)	<input type="checkbox"/>
U0 angle (135)	<input type="checkbox"/>	U12 angle (136)	<input type="checkbox"/>	U23 angle (137)	<input type="checkbox"/>	U31 angle (138)	<input type="checkbox"/>	Ip+ (139)	<input type="checkbox"/>
Ip+ angle (140)	<input type="checkbox"/>	Ip- (141)	<input type="checkbox"/>	Ip- angle (142)	<input type="checkbox"/>	I1 ch2 (143)	<input type="checkbox"/>	I2 ch2 (144)	<input type="checkbox"/>
I3 ch2 (145)	<input type="checkbox"/>	I0 ch2 (146)	<input type="checkbox"/>	I1 angle ch2 (147)	<input type="checkbox"/>	I2 angle ch2 (148)	<input type="checkbox"/>	I3 angle ch2 (149)	<input type="checkbox"/>
I0 angle ch2 (150)	<input type="checkbox"/>	Ip+ ch2 (151)	<input type="checkbox"/>	Ip+ angle ch2 (152)	<input type="checkbox"/>	Ip- ch2 (153)	<input type="checkbox"/>	Ip- angle ch2 (154)	<input type="checkbox"/>

Fig. 5.3.1 IOMod FPI Data select tab view

5.4 Diagnostics

IOMod Utility Diagnostics tab allows real-time monitoring of IOMod FPI measurements and detection function statuses. The diagnostics mode of both measurements and detection statuses is turned off by default. This is indicated by the red "Offline" word designation and by the unchanging black circle (Fig. 5.4.1, Fig. 5.4.2).


General info		Communication settings		Iomod settings		Diagnostics	
Measurements		Detection Status					
<div>Connect</div> <div>Offline </div>							
P	0.00kW	Q	0.00kVAr	S	0.00kVA		
PF	0.000	Frequency	0.00Hz				
Active energy import		0kWh		Reactive energy import		0kVArh	
Active energy export		0kWh		Reactive energy export		0kVArh	
I1	0A	0°	--	I2	0A	0°	--
I3	0A	0°	--	I0	0A	0°	U0
U1	0	0°	U2	0	0°	U3	0
U12	0	0°	U23	0	0°	U31	0
Ip	0A	0°	In	0A	0°		
P1	0.0kW	P2	0.0kW	P3	0.0kW		
Q1	0.0kVAr	Q2	0.0kVAr	Q3	0.0kVAr		
S1	0.0kVA	S2	0.0kVA	S3	0.0kVA		
PF1	0.000	PF2	0.000	PF3	0.000		

Fig. 5.4.1 IOMod Utility Diagnostics tab Measurement section in offline mode


General info		Communication settings		Iomod settings		Diagnostics	
Measurements		Detection Status					
<div>Connect</div> <div>Offline </div>							
Clear faults							
50							pickup trip
							<input type="checkbox"/> <input type="checkbox"/>
67	pickup	A	B	L1	L2	L3	Inrush
	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
50N							pickup trip
							<input type="checkbox"/> <input type="checkbox"/>
51N							pickup trip
							<input type="checkbox"/> <input type="checkbox"/>
67N	pickup	A	B				
	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>				
Permanent earth fault (59N)							pickup trip
							<input type="checkbox"/> <input type="checkbox"/>
Overvoltage (59)							warning alarm
							<input type="checkbox"/> <input type="checkbox"/>
Undervoltage (27)							warning alarm
							<input type="checkbox"/> <input type="checkbox"/>
Phase sequence (47)							abc acb
							<input checked="" type="checkbox"/> <input type="checkbox"/>

Fig. 5.4.2 IOMod Utility Diagnostics tab Detection Status section in offline mode

In order to turn on real-time monitoring of both Diagnostics sections, "Connect" button to the left of "Offline" word designation needs to be pressed. The button can be pressed in either Diagnostics sections (Measurements or Detection Status). After pressing "Connect" button the word designation of Diagnostics mode changes to "Online", the black circle starts blinking and the button name changes to "Disconnect" (Fig. 5.4.3, Fig. 5.4.4). When a fault is

detected the checkboxes which are opposite the according detection functions are going to be checked (Fig. 5.4.4).

General info		Communication settings		Iomod settings		Diagnostics	
Measurements		Detection Status					
<div>Disconnect</div> <div>Online ●</div>							
P	2997.11kW	Q	-1.15kVAr	S	2995.38kVA		
PF	1.000	Frequency	49.98Hz				
Active energy import	579kWh	Reactive energy import	0kVArh				
Active energy export	0kWh	Reactive energy export	0kVArh				
I1	100A	0°	A↑	I2	100A	240°	A↑
I3	100A	120°	A↑	U1	9988	0°	
U2	9988	240°		U3	9988	120°	
U12	17304	30°		U23	17304	270°	
U31	17298	150°		I0	0A	92°	
U0	6	54°		Ip	100A	360°	
In	0A	0°		P1	998.8kW	P2	998.3kW
P3	999.4kW	Q1	-0.6kVAr	Q2	-0.6kVAr	Q3	0.0kVAr
S1	998.3kVA	S2	997.7kVA	S3	998.8kVA	PF1	1.000
PF2	1.000	PF3	1.000				

Fig. 5.4.3 IOMod Utility Diagnostics tab Measurement section in online mode




Fig. 5.4.4 IOMod Utility Diagnostics tab Detection status section in online mode

It is advisable to turn off Diagnostics mode before setting new IOMod FPI parameters. In order to turn off Diagnostics real-time monitoring mode, "Disconnect" button needs to be pressed.

6. Device functions

6.1 Instantaneous overcurrent detection function (50)

It is a three phase overcurrent detection function with the definite time characteristic. This function is intended for detecting electrical faults in medium voltage three phase networks, e.g. short circuits and overloading.

During the instantaneous overcurrent detection process (Fig. 6.1.1) RMS value of each phase fundamental frequency current is constantly being obtained. While first and third phase currents are always measured, the way of obtaining RMS values of the second phase is dependent upon neutral current value obtaining mode. In case of I_0 metered mode the RMS value of the second phase current is being calculated as a vector sum of the I_1 , I_3 and I_0 current values. If instead the neutral current is being calculated, then the current of the second phase is being measured. After obtaining current level values they are being compared with a configured threshold designated as I_{pickup} . If a phase current in any line exceeds Pickup current I_{pickup} , then "Instantaneous overcurrent function (50) pickup" signal with the address 10 is issued (Table 7.1.1, Table 7.2.1, Table 7.3.1). The further actions are delayed by a preconfigured amount of time to filter out any momentary current level spikes. If the level of a phase current in any line remains higher than I_{pickup} for a time longer than a Time delay parameter value specifies, then "Instantaneous overcurrent function (50) operated" signal with the address 0 is issued. Finally, from one to three signals are sent identifying the line or the lines in which the overcurrent conditions were detected: "Overcurrent fault in the first phase (L_1)" with the address 6, "Overcurrent fault in the second phase (L_2)" with the address 7, "Overcurrent fault in the third phase (L_3)" with the address 8.




Fig. 6.1.1 Instantaneous overcurrent protection function algorithm structural diagram

The instantaneous overcurrent detection function has two main parameters (Table 6.1.1): Pickup current and Time delay. The table below describes the range and default values of the parameters.

Table 6.1.1 Instantaneous overcurrent protection function related parameters with their ranges and default values

Parameter	Range	Default value
50 I>	Enabled / Disabled	Disabled
Pickup current (A)	1-1000	300
Time delay (ms)	40-60000	100

IOMod Utility is required to enable the instantaneous overcurrent detection in FPI. In IOMod Utility go to Iomod settings -> Protection. There find "50 I>" function. Modify the parameters if required and tick the box next to the function name to enable it (Fig 6.1.2).

Fig. 6.1.2 IOMod Utility instantaneous overcurrent detection function configuration view

6.2 Instantaneous overcurrent earth fault detection function (50N)

It is a residual ground overcurrent detection function with definite time characteristic. This function is intended for phase to ground fault detection in medium voltage three phase networks.

During the instantaneous overcurrent earth fault detection process (Fig. 6.2.1) RMS value of fundamental frequency neutral current is constantly being obtained. Two modes of obtaining RMS values of the neutral current are available: metered and calculated. In case of I_0 metered mode the neutral current is being measured directly. In the "calculated" mode the neutral current is being calculated as a vector sum of three phase current values. After obtaining neutral current level it is compared with the configured threshold I_{pickup} . If the neutral current exceeds Pickup current I_{pickup} , "Instantaneous overcurrent earth fault function (50N) pickup" signal with the address 11 (Table 7.1.1, Table 7.2.1, Table 7.3.1) is issued. The further actions are delayed by a preconfigured amount of time to filter out any momentary current level spikes. If the level of the neutral current remains higher than I_{pickup} for a time longer than a Time delay parameter specifies, then "Instantaneous overcurrent earth fault function (50N) operated" signal with the address 1 is issued.




Fig. 6.2.1 Instantaneous overcurrent earth fault protection function algorithm structural diagram

The instantaneous overcurrent earth fault detection function has two main parameters (Table 6.2.1): Pickup current and Time delay. The table below describes the range and default values of the parameters.

Table 6.2.1 Instantaneous overcurrent earth fault protection function related parameters with their ranges and default values

Parameter	Range	Default value
50 In	Enabled / Disabled	Disabled
Pickup current (A)	1-1000	200
Time delay (ms)	40-60000	100

IOMod Utility is required to enable the instantaneous overcurrent earth fault detection in FPI. In IOMod Utility go to Iomod settings -> Protection. There find "50 In" function. Modify the parameters (Table 6.2.1) if required and tick the box next to the function name to enable it (Fig 6.2.2).

Fig. 6.2.2 IOMod Utility instantaneous overcurrent earth fault detection function configuration view

6.3 Undervoltage detection function (27)

Undervoltage detection function is intended for detecting abnormally low voltage levels in three phase networks. The function defines two thresholds in relative units (Table 6.3.1, Fig. 6.3.3) - "Pickup voltage warning (%)" and "Pickup voltage alarm (%)". Based on which threshold is surpassed warning or alarm signal is sent respectively (Fig 6.3.1, Fig 6.3.2).




Fig. 6.3.1. Warning-level undervoltage detection function algorithm structural diagram




Fig. 6.3.2 Alarm-level undervoltage detection function algorithm structural diagram

Each phase voltage is constantly being monitored and compared with each of previously mentioned thresholds. The subsequent operation depends on the selected logic. The "Logic" parameter (Table 6.3.1, Fig. 6.3.2) defines the conditions when the alarm or warning signal is issued. If "Logic" parameter is set to "AND", a warning or alarm is triggered if the voltage level in *all* of the three phases falls below the respective threshold value. If "Logic" is set to "OR", a warning or alarm is triggered if the voltage level in *any* of the three phases falls below the respective threshold value. The further sending of a certain signal is delayed by a configured amount of time to filter out any momentary voltage level dips. If after the time delay the voltage level remains lower than one of the pickup thresholds, warning or alarm signal is sent. The "Undervoltage (27) warning" signal, assigned to address 18 (Fig. 6.3.1), is triggered if any or all nominal voltage levels drop by the percentage defined in the "Pickup Voltage Warning (%)" parameter. Similarly, the "Undervoltage (27) alarm" signal, assigned to address 19 (Fig 6.3.2), is sent if any or all nominal voltage levels drop by the percentage defined in the "Pickup Voltage Alarm (%)" parameter.

The undervoltage detection function has four parameters (Table 6.3.1): Pickup voltage warning, Pickup voltage alarm, Logic and Time delay. The table below describes the range and default values of the parameters.

Table 6.3.1 Undervoltage detection function related parameters with their ranges and default values

Parameter	Range	Default value
27	Enabled / Disabled	Disabled
Pickup voltage warning (%)	1-100	30
Pickup voltage alarm (%)	1-100	20
Logic	AND / OR	AND
Time delay (ms)	40-60000	1000

IOMod Utility is required to enable the undervoltage detection in FPI. In IOMod Utility go to Iomod settings -> Protection. There find "27" function. Modify the parameters if required and tick the box next to the function name to enable it (Fig 6.3.2).

Fig. 6.3.3 IOMod Utility undervoltage detection function configuration view

6.4 Overvoltage detection function (59)

Undervoltage detection function is intended for detecting abnormally high voltage levels in three phase networks. The function defines two thresholds in relative units (Table 6.4.1, Fig. 6.4.3) - "Pickup voltage warning (%)" and "Pickup voltage alarm (%)". Based on which threshold is surpassed warning or alarm signal is sent respectively (Fig 6.4.1, Fig 6.4.2).




Fig. 6.4.1 Warning-level overvoltage detection function algorithm structural diagram




Fig. 6.4.2 Alarm-level overvoltage detection function algorithm structural diagram

Each phase voltage is constantly being monitored and compared with each of previously mentioned thresholds. The subsequent operation depends on the selected logic. The "Logic" parameter (Table 6.4.1, Fig. 6.4.3) defines the conditions when the alarm or warning signal is issued. If "Logic" parameter is set to "AND", a warning or alarm is triggered if the voltage level in *all* of the three phases exceeds the respective threshold value. If "Logic" is set to "OR", a warning or alarm is triggered if the voltage level in *any* of the three phases exceeds the respective threshold value. The further sending of one of the signals is delayed by a configured amount of time to filter out any momentary voltage level spikes. If after the time delay the voltage level remains higher than one of the pickup thresholds, warning or alarm signal is sent. The "Overvoltage (59) warning" signal, assigned to address 16 (Fig. 6.4.1), is triggered if any or all nominal voltage levels increases by the percentage defined in the "Pickup Voltage Warning (%)" parameter. Similarly, the "Overvoltage (59) alarm" signal, assigned to address 17 (Fig 6.4.2), is sent if any or all nominal voltage levels increases by the percentage defined in the "Pickup Voltage Alarm (%)" parameter.

The overvoltage detection function has four parameters (Table 6.4.1): Pickup voltage warning, Pickup voltage alarm, Logic and Time delay. The table below describes the range and default values of the parameters.

Table 6.4.1 Overvoltage detection function related parameters with their ranges and default values

Parameter	Range	Default value
59	Enabled / disabled	Disabled
Pickup voltage warning (%)	100-200	110
Pickup voltage alarm (%)	100-200	120
Logic	AND / OR	AND
Time delay (ms)	40-60000	1000

IOMod Utility is required to enable the overvoltage detection in FPI. In IOMod Utility go to Iomod settings -> Protection. There find "59" function. Modify the parameters if required and tick the box next to the function name to enable it (Fig 6.4.2).

59 ☐

Pickup voltage warning (%)

Pickup voltage alarm (%)

Logic

Time delay (ms)

Fig. 6.4.3 IOMod Utility overvoltage detection function configuration view

6.5 Earth fault overvoltage detection (59N)

Earth fault overvoltage detection function is intended for detecting abnormally high level of zero sequence voltage in three phase networks. The neutral voltage is being calculated by taking the vector sum of fundamental frequency components of measured voltages (Fig 6.5.1). The calculated neutral voltage is constantly being compared with the neutral voltage threshold value U_{pickup} . The value of U_{pickup} is calculated by taking percentage, which is defined in "Pickup voltage (%)" parameter, of its nominal value. Right after detecting a neutral voltage which crosses U_{pickup} limit, the "Residual overvoltage (59N) pickup" signal, assigned to address 15, is sent. The further sending of "operated" signal is delayed by a configured amount of time to filter out any momentary neutral voltage spikes. If the level of the neutral voltage remains higher than U_{pickup} for the time longer than a Time delay parameter specifies, then "Residual overvoltage (59N) operated" signal, assigned to address 9, is issued.




Fig. 6.5.1 Earth fault overvoltage detection function algorithm structural diagram

The overvoltage detection function has two parameters (Table 6.5.1): Pickup voltage and Time delay. The table below describes the range and default values of the parameters.

Table 6.5.1 Overvoltage detection function related parameters with their ranges and default values

Parameter	Range	Default value
59N	Enabled / disabled	Disabled
Pickup voltage (%)	0-100	30
Time delay (ms)	40-60000	10000

IOMod Utility is required to enable the earth fault overvoltage detection in FPI. In IOMod Utility go to Iomod settings -> Protection. There find "59N" function. Modify the parameters if required and tick the box next to the function name to enable it (Fig 6.5.2).

59N ☒

Pickup voltage (%)

Time delay (ms)

Fig. 6.5.2 IOMod Utility earth fault overvoltage detection function configuration view

6.6 Directional overcurrent detection function (67)

It is a directional phase fault detection function with definite or inverse time characteristic. This function is intended for

detecting phase faults in medium voltage three phase networks with fault direction determination.

The directional overcurrent detection function has six parameters (Table 6.6.1): Pickup current, IDMT curve, TMS, Time delay, Correction angle and Inrush blocking. The table below describes the range and default values of the parameters.

Table 6.6.1 Directional phase fault detection function parameters.

Parameter	Range	Default value
67/51	Enabled / disabled	Disabled
Pickup current (A)	1-1000	200
IDMT curve	Time delay*	Standard inverse
	Standard inverse	
	Very inverse	
	Extremely inverse	
	Long time inverse	
TMS (time multiplier)	0.01-100	1
Time delay (ms)	40-60000	100
Correction angle (MTA)	-80°... 80°	-45°
Inrush blocking	Enabled / Disabled	Enabled

* Definite time delay

IOMod Utility is required to enable the directional overcurrent detection in FPI. In IOMod Utility go to Iomod settings -> Protection. There find "67/51" function. Modify the parameters if required and tick the box next to the function name to enable it (Fig 6.6.2).

67/51

Pickup current (A)

200

IDMT curve

Standard inverse

TMS

1.0

Time delay (ms)

100

Correction angle

-45

Inrush blocking

Fig. 6.6.1 IOMod Utility directional overcurrent detection function configuration view

Describing directional overcurrent detection function algorithm, it is important to notice that both current and voltage measurements are required (Fig 6.6.3). Similarly to Instantaneous overcurrent function (50), each phase currents are being continually measured and compared with the preconfigured Pickup current value I_{pickup} . Assuming that Inrush check is disabled, after detecting the crossing of I_{pickup} by any of the currents, "Directional overcurrent function (67) pickup" signal, assigned to address 12, is sent. If the Inrush blocking detection function (81) is enabled, the second harmonic of each phase is obtained and compared to I_{h2}/I_{h1} parameter value (Table 6.6.3.1). The level of a current

second harmonic must exceed the Inrush threshold value for a time longer than Time delay parameter specifies. If these conditions are fulfilled, then the Inrush current is detected and "Blocking by 2nd harmonic active" signal with address 14 is issued. The detection of the Inrush current blocks the subsequent operation and the "Directional overcurrent function (67) pickup" signal is not sent.




Fig. 6.6.2 Directional overcurrent detection function algorithm structural diagram

Similarly to the function 50 overcurrent detection activation signal is postponed by a preconfigured time, in order to filter any short-term current spikes. However, this time apart from definite time delay, there is an option to set Inverse Definite Minimum Time (IDMT) delay. In contrast to the Definite time delay, IDMT delay period depends on the overcurrent amplitude. The bigger the overcurrent amplitude, the shorter the delay. IDMT time delay can be calculated by using the formula below:

$$T = TMS \times \frac{K}{\left(\frac{I}{I_{pickup}}\right)^n - 1}$$

Where:

- T - operating time of the relay (in seconds)
- TMS - Time Multiplier Setting (adjusts the speed of operation)
- K - Constant specific to the IDMT curve type (depends on the curve type, Table 6.6.2)
- I - Fault current (in amperes)
- I_{pickup} - Pickup current (in amperes)
- n - Characteristic exponent (depends on the curve type, see Table 6.6.2)

IEC 60255 standard describes four main curve characteristics (Table 6.6.2). Each characteristic defines a unique pair of K and n coefficients:

Table 6.6.2 Parameters of IEC Characteristic Curves.

Curve Type	K	n
------------	-----	-----

Standard (Normal) Inverse	0.14	0.02
Very Inverse	13.5	1
Extremely Inverse	80	2
Long Time Inverse	120	1

Plotting all four curve types helps to visualize how the time delay depends on the fault current for each characteristic, providing a clear comparison of their different response behaviors (Fig. 6.6.4). All curves were calculated with TMS parameter set to 1.




Fig. 6.6.3 IDMT Time Delay dependence on the fault current graphs (with TMS=1)

IDMT time delay characteristics can be adjusted by changing TMS values. Decreasing or increasing TMS value changes the vertical position of IDMT curves placing them lower or higher respectively (Fig. 6.6.5). In other words, by decreasing or increasing the TMS value, you can make the time delay shorter or longer, respectively.




Fig. 6.6.4 The effect of TMS parameter on IDMT curves (on the left: TMS=0.01, on the right: TMS=100)

Setting IDMT curve value to "Time delay" switches to Definite time delay mode. In this mode time delay value is constant and does not depend on the fault current. The value of the constant time delay is adjusted by the "Time delay (ms)" parameter (Fig. 6.6.2).

Besides the overcurrent detection, the direction of the fault current is determined. In order to be able to provide directional overcurrent fault information RMS values and the phase angles of the fundamental frequency currents and voltages are constantly being measured. Quadrature voltages are used for determining the direction of a fault, e.g. for determining the direction of the first phase current I_1 fault phase to phase voltage U_{23} is used. Based on the angle between the voltage and current, the relay can distinguish between Direction A (forward) and Direction B (reverse). In most power systems, Direction A would be the flow of current towards the load or downstream side (away from the source). On the other hand, Direction B would be the flow of current back towards the source or upstream side (against the normal flow of current). The minimal voltage level for which direction determination still can be performed is 10 % of nominal. The characteristic angle or so-called maximum torque angle (MTA) can be set by a user (Table 6.6.1, Fig. 6.6.2). It defines the angle between a phase current and a corresponding phase voltage (Fig. 6.6.1). Typically, a phase fault is inductive in its nature, meaning that current lags voltage, therefore default value of "Correction angle" parameter is set to -45° . Forward direction (dir A) zone is in window "Correction angle" $\pm 88^\circ$, reverse direction (dir B) zone is in opposite $\pm 88^\circ$ window, 4° gap between forward and reverse zones is an undetermined area. If polarization voltage is below 10 % or the angle between the fault current and voltage is in the undetermined area, then function works as non-directional overcurrent function and activates both directional elements, i.e. A and B.




Fig. 6.6.5 Overcurrent direction determination phasor diagram

If after a Time delay the level of the fault current in any line remains higher than I_{pickup} , then, depending on the fault direction, "Overcurrent function (67) direction A operated" signal, assigned to address 2, or "Overcurrent function (67) direction B operated" signal, assigned to address 3, is issued. However, if the direction could not be determined both signals are going to be issued. Also, similarly to the function 50, from one to three signals are sent identifying the line or the lines in which the overcurrent conditions were detected: "Overcurrent fault in the first phase (L_1)" (assigned to address 6), "Overcurrent fault in the second phase (L_2)" (assigned to address 7), "Overcurrent fault in the third phase (L_3)" (assigned to address 8).

6.6.1 Inverse time overcurrent detection function (51)

By switching to 3I3I connection mode the detection function 67 becomes the detection function 51. Their operational algorithms are quite similar (Fig. 6.6.1.1), but the absence of the voltage measurements brings some important differences. Each phase currents of two feeders are continually measured and compared with the preconfigured Pickup current value I_{pickup} . The Pickup current can be separately configured for each channel.

In the context of the first channel (Fig. 6.6.1.1), if the Inrush check is disabled, after detecting the crossing of I_{pickup} by any of the currents, "Directional overcurrent function (67) pickup" signal, assigned to address 12, is sent. If the Inrush blocking detection function (81) is enabled, the second harmonic of each phase is obtained and compared to I_{h2}/I_{h1} parameter value (Table 6.6.3.1). The level of a current second harmonic must exceed the Inrush threshold value for a time longer than Time delay parameter specifies. If these conditions are fulfilled, then the Inrush current is detected and "Blocking by 2nd harmonic active" signal with address 14 is issued. The detection of the Inrush current blocks the subsequent operation and the "Directional overcurrent function (67) pickup" signal is not sent. Assuming that an overcurrent was detected and was not blocked by an Inrush current, the subsequent operation is delayed by a definite or inverse time period. Since the voltage measurements are not obtained, the fault direction cannot be determined. Due to this fact, if the overcurrent is still detected after the time delay, two signals are sent: "Overcurrent function (67) direction A operated", assigned to address 2, and "Overcurrent function (67) direction B operated", assigned to address 3, identifying both directions. Also, from one to three signals are sent identifying the line or the lines in which the overcurrent conditions were detected: "Overcurrent fault in the first phase (L_1)" (assigned to address 6), "Overcurrent fault in the second phase (L_2)" (assigned to address 7), "Overcurrent fault in the third phase (L_3)" (assigned to address 8).




Fig. 6.6.1.1 Inverse time overcurrent first channel detection function algorithm structural diagram

In case of the second channel (Fig. 6.6.1.2), if the Inrush check is disabled or Inrush current is not detected, after detecting the crossing of I_{pickup} by any of the currents, "Time inverse overcurrent function (51) pickup in channel 2" signal, assigned to address 41, is sent. Assuming that an inrush current was detected in any of phases, the subsequent operation is blocked and "Blocking by 2nd harmonic active in channel 2" signal, assigned to address 43 is issued. Assuming that an overcurrent was detected and was not blocked by an Inrush current, the subsequent operation is delayed by a definite or inverse time period. Contrary to the first channel, if the overcurrent is still detected after the time delay, only one signal is issued: "Time inverse overcurrent function (51) operated in channel 2", assigned to address 34. Also, from one to three signals are sent identifying the line or the lines in which the overcurrent conditions were detected: "Overcurrent fault in phase L_1 of channel 2" (assigned to address 36), "Overcurrent fault in phase L_2 of channel 2" (assigned to address 37), "Overcurrent fault in phase L_3 of channel 2" (assigned to address 38).




Fig. 6.6.1.2 Inverse time overcurrent second channel detection function algorithm structural diagram

The inverse time overcurrent detection function has five parameters (Table 6.6.1.1): Pickup current, IDMT curve, TMS, Time delay and Inrush blocking. The table below describes the range and default values of the parameters.

Table 6.6.1.1 Inverse time overcurrent detection function parameters.

Parameter	Range	Default value
51	Enabled / disabled	Disabled
Pickup current (A)	1-1000	200
IDMT curve	Time delay (IDMT off)	Standard inverse
	Standard inverse	
	Very inverse	
	Extremely inverse	
	Long time inverse	
TMS (time multiplier)	0.01-100	1.0
Time delay (ms)	40-60000	100
Inrush blocking	Enabled / Disabled	Enabled

IOMod Utility is required to enable the directional overcurrent detection in FPI. In IOMod Utility go to Iomod settings -> Protection. There find "51" function. Modify the parameters if required and tick the box next to the function name to enable it (Fig. 6.6.1.3).

51 ☐

Pickup current (A)

IDMT curve

TMS

Time delay (ms)

Inrush blocking ☐

Fig. 6.6.1.3 IMod Utility inverse time overcurrent detection function configuration view

6.6.2 Inverse time overcurrent earth fault detection function (51N)

In the 3I3I connection mode the Inverse time overcurrent earth fault detection function (51N) is available. This function algorithm (Fig. 6.6.2.1, Fig. 6.6.2.2) is similar to the Instantaneous overcurrent earth fault detection function (50N) algorithm (Fig. 6.2.1). The key differences of function 51N are the presence of two channels and the ability to select between the Inverse time or Definite time delays. Similarly to the function 50N, RMS value of fundamental frequency neutral current is constantly being obtained. Two modes of obtaining RMS values of the neutral current are available: metered and calculated. In the case of I0 metered mode the neutral current is being measured directly. In the "calculated" mode the neutral current is being calculated as a vector sum of three phase current values. After obtaining neutral current level it is compared with the configured threshold I_{pickup} . The Pickup current and Time delay parameters can be separately configured for each channel.

In case of the first channel (Fig. 6.6.2.1), if the neutral current exceeds Pickup current/ I_{pickup} , "Time inverse overcurrent earth fault function (51N) pickup" signal with the address 27 is issued. The subsequent operation is delayed by a definite or inverse time period. If the earth fault conditions remains after the time delay, "Time inverse overcurrent earth fault function (51N) operated" signal with address 28 is issued.




Fig. 6.6.2.1 Inverse time overcurrent earth fault first channel detection function algorithm structural diagram

In the context of the second channel (Fig. 6.6.2.2), if the neutral current exceeds Pickup current/ I_{pickup} , "Time inverse overcurrent earth fault function (51N) pickup in channel 2" signal, assigned to address 42, is issued. The subsequent operation is delayed by a definite or inverse time period. If the earth fault conditions remains after the time delay,

"Time inverse overcurrent earth fault function (51N) operated in channel 2" signal, assigned to address 35, is issued.




Fig. 6.6.2.2 Inverse time overcurrent earth fault second channel detection function algorithm structural diagram

The inverse time overcurrent earth fault detection function has four parameters (Table 6.6.2.1): Pickup current, IDMT curve, TMS and Time delay. The table below describes the range and default values of the parameters.

Table 6.6.2.1 Inverse time overcurrent earth fault detection function parameters.

Parameter	Range	Default value
51N	Enabled / disabled	Disabled
Pickup current (A)	1-1000	200
IDMT curve	Time delay (IDMT off)	Standard inverse
	Standard inverse	
	Very inverse	
	Extremely inverse	
	Long time inverse	
TMS (time multiplier)	0.01-100	1.0
Time delay (ms)	40-60000	100

IOMod Utility is required to enable the directional overcurrent detection in FPI. In IOMod Utility go to Iomod settings -> Protection. There find "51N" function. Modify the parameters if required and tick the box next to the function name to enable it (Fig. 6.6.2.3).

Fig. 6.6.2.3 IOMod Utility inverse time overcurrent earth fault detection function configuration view

6.6.3 Inrush blocking detection function (81)

Directional phase fault detection function (67) has inrush blocking functionality. If the function is enabled, the 2nd harmonic level of a phase current is monitored. If a phase current 2nd harmonic level is higher than a configured threshold value for a longer time than the "Time delay" parameter specifies, then Inrush current is detected and the overcurrent in any line is ignored (see Fig 6.6.3, Fig. 6.6.1.1 and Fig. 6.6.1.2). Notice that the function cannot be enabled separately, because it works as a part of over detection functions, namely: 67 and 51. This function can be enabled by the "Inrush blocking" checkbox, which can be found in the settings of 67 and 51 functions (Fig. 6.6.1, Fig. 6.6.1.3).

Table 6.6.3.1 Inrush blocking parameters.

Parameter	Range	Default value
I_{h2}/I_{h1} (2nd harmonic level)	0-100 %	15 %
Time delay (ms)	40-60000	100

IOMod Utility is required to control the operation of the inrush blocking detection function in FPI. In IOMod Utility go to Iomod settings -> Protection. There find "81 Inrush" function. Modify the parameters if required (Fig 6.6.3.1).

Fig. 6.6.3.1 IOMod Utility inrush blocking detection function configuration view

6.7 Directional overcurrent earth fault detection function (67N)

It is a ground fault detection function with definite time characteristic and fault direction determination. This function is intended for detecting phase to ground faults in medium voltage three phase networks. In order to provide directional overcurrent earth fault information, the ground current and the residual voltage are constantly being monitored. The ground fault current is calculated as the value of the vector sum of the three phase currents or measured with zero sequence current transformer (core balanced CT - CBCT) (Fig. 7.6.1). Residual voltage is always calculated as vector sum of three phase voltages. Three conditions must be met for the "Directional earth fault function (67N) pickup" signal, assigned to address 13, to be issued. Firstly, the ground fault current I_0 must exceed the pickup current I_{pickup} . Secondly, the relative residual voltage U_0 must exceed the "Minimum U_0 (%)" parameter value. The relative residual voltage is calculated relatively to the nominal value of a phase current. In case when "Directional Current (A)" parameter is set to 0 or Grounding parameter is set to "Solid" (see Fig. 5.1.1), the fulfillment of the two previous conditions is sufficient for the "Pickup" signal to be sent. In the other case, for the "Pickup" signal to be sent, the specific component of the fault current must be greater than the directional current parameter I_{dir} value. The usage of the ground fault current components for ground fault current detection is going to be discussed later in detail. The angle and the direction of the fault current are determined by using the ground fault current along with the residual voltage. The angle depends on the network grounding method: solid, isolated or compensated. The correction angle of solidly grounded system is equal to -45° and cannot be configured. The direction of the fault current can be either A (forward) or B (reverse). In most power systems, Direction A would be the flow of current towards the load or downstream side (away from the source). On the other hand, Direction B would be the flow of current back towards the source or upstream side (against the normal flow of current). If the pickup conditions persist for a time longer than "Time delay" parameter specifies, then, depending on the fault direction, "Earth fault (67N) direction A operated" signal, assigned to address 4, or "Earth fault (67N) direction B operated" signal, assigned to address 5, is issued.




Fig. 6.7.1 Directional overcurrent earth fault detection function algorithm structural diagram

In addition to the vector based method there is a possibility to enable $\sin(\varphi)$ or $\cos(\varphi)$ method for ground fault detection using the directional current (I_{dir}) parameter. However, these methods are applicable for isolated or compensated ground networks only. The directional current I_{dir} defines the thresholds of the reactive $I_0\sin(\varphi)$ part or the active $I_0\cos(\varphi)$ of the ground current for the isolated ground or the resonant grounding networks respectively. In case of an isolated-ground network (Fig. 6.7.2) the device indicates the earth fault when the total ground current and the reactive current $I_0\sin(\varphi)$ is higher than the pickup current I_{pickup} and the directional current I_{dir} for a time longer that "Time delay" parameter specifies. However, if the directional current I_{dir} is set to 0, only total ground current is used for the fault detection.




Fig. 6.7.2 ' $I_0\sin$ ' characteristic for an isolated neutral network

For a resonant (or 'compensated ') grounding network (Fig. 6.7.3) the device indicates the earth fault when total ground current and active current $I_0\cos(\varphi)$ is bigger that the pickup current I_{pickup} and the directional current I_{dir} for a time longer that "Time delay" parameter specifies. However, if the directional current I_{dir} is set to 0, only total ground current is used for the fault detection.




Fig. 6.7.3 ' $I_0\cos$ ' characteristic for a resonant network

The directional overcurrent earth fault detection function has four parameters (Table 6.7.1): Pickup current, Directional current, Minimum U_0 and Time delay. The table below describes the range and default values of the parameters.

Table 6.7.1 Directional earth fault detection function parameters.

Parameter	Range	Default value
67N	Enabled / disabled	Disabled
Pickup Current (A)	0-1000	30
Directional Current (A)	0-1000	5
Minimum U_0 (%)	0-100	20
Time delay (ms)	40-60000	1000

IOMod Utility is required to enable the directional overcurrent earth fault detection in FPI. In IOMod Utility go to Iomod settings -> Protection. There find "67N" function. Modify the parameters if required and tick the box next to the function name to enable it (Fig 6.7.4).

67N
☐

Pickup current (A)

Directional current (A)

Minimum U_0 (%)

Time delay (ms)

Fig. 6.7.4 IOMod Utility directional overcurrent earth fault

7. Communication protocols

IOMod FPI supports three communication protocols: Modbus RTU, IEC 60870-5-101 and IEC 60870-5-103. By means of these communication protocols a user via a master device is able to read from the device the measured data as well as fault detection statuses. Also, the protocols allow a master device to send a command to clear fault detection statuses. Communication protocol can be selected by means of IOMod Utility (IOMod Utility manual can be accessed [here](#)).

7.1 Modbus RTU operational information

Modbus RTU protocol is a simple and widely used messaging structure for serial communication. In the case of Modbus protocol IOMod FPI will send data only after receiving correct queries from a master device.

Only three function codes are supported: FC2, FC4 and FC5. Read Discrete Inputs function, which is denoted by function code 2 (FC2), as its name implies is designed for reading digital data. In the context of IOMod FPI FC2 requests allow to read fault detection statuses (Table 7.1.1). It should be noted that the fault statuses cannot be overwritten separately but can only be read (R access).

Table 7.1.1 List of discrete inputs with fault detection statuses. The data can be read using Modbus FC2 request.

Address (Dec)	Description	Access
0	Instantaneous overcurrent function (50) operated	R
1	Instantaneous overcurrent earth fault function (50N) operated	R
2	Overcurrent function (67) direction A operated	R
3	Overcurrent function (67) direction B operated	R
4	Earth fault (67N) direction A operated	R
5	Earth fault (67N) direction B operated	R
6	Overcurrent fault in the first phase (I_1)	R
7	Overcurrent fault in the second phase (I_2)	R
8	Overcurrent fault in the third phase (I_3)	R
9	Residual overvoltage (59N) operated	R
10	Instantaneous overcurrent function (50) pickup	R
11	Instantaneous overcurrent earth fault function (50N) pickup	R
12	Directional overcurrent function (67) pickup	R
13	Directional earth fault function (67N) pickup	R
14	Blocking by 2nd harmonic active	R
15	Residual overvoltage (59N) pickup	R
16	Overvoltage (59) warning	R

17	Overvoltage (59) alarm	R
18	Undervoltage (27) warning	R
19	Undervoltage (27) alarm	R
20	Active power of the first phase (I_1) in direction A	R
21	Active power of the first phase (I_1) in direction B	R
22	Active power of the second phase (I_2) in direction A	R
23	Active power of the second phase (I_2) in direction B	R
24	Active power of the third phase (I_3) in direction A	R
25	Active power of the third phase (I_3) in direction B	R
26	Reverse phase rotation	R
27	Time inverse overcurrent earth fault function (51N) pickup	R
28	Time inverse overcurrent earth fault function (51N) operated	R
29	Reserved	R
30	Reserved	R
31	Reserved	R
32	Instantaneous overcurrent function (50) operated in channel 2	R
33	Instantaneous overcurrent earth fault function (50N) operated in channel 2	R
34	Time inverse overcurrent function (51) operated in channel 2	R
35	Time inverse overcurrent earth fault function (51N) operated in channel 2	R
36	Overcurrent fault in phase I_1 of channel 2	R
37	Overcurrent fault in phase I_2 of channel 2	R
38	Overcurrent fault in phase I_3 of channel 2	R
39	Instantaneous overcurrent function (50) pickup in channel 2	R
40	Instantaneous overcurrent earth fault function (50N) pickup in channel 2	R
41	Time inverse overcurrent function (51) pickup in channel 2	R
42	Time inverse overcurrent earth fault function (51N) pickup in channel 2	R

43	Blocking by 2nd harmonic active in channel 2	R
----	----------------------------------------------	---

Nevertheless, all fault detection statuses can be reset at once by sending an activation command to a coil with address 1 (Table 7.1.2). It can be done by using Write Single Coil function, which is denoted with a function code 5 (FC5). A value of 0xFF00 should be used to form an activation request with an FC5 request.

Table 7.1.2 List of coils with Device Control Signals.

Address (Dec)	Description	Access	Modbus Function
1	Clear faults	W	5

The measured data can read with Read Input Registers Modbus function, which code is 4 (FC4). There are three groups of measured data stored in IOMod FPI. The first group of registers stores data in the integer format (Table 7.1.3). All current, voltage and power measurements belonging to this group are presented in the scaled relative units. These values are calculated by taking the percentage from its nominal value and multiplying it by 10. All phase angles belonging to this group are presented in degrees and multiplied by 10 to preserve the precision of 1. Also, all power factors belonging to this group are multiplied by 1000 to preserve the precision of 3.

Table 7.1.3 Nominal values in integer format. The data can be read using Modbus FC4 request.

Address (Dec)	Description	Units	Data type	Access
0	Current I_1	% x 10	UINT16	R
1	Current I_2	% x 10	UINT16	R
2	Current I_3	% x 10	UINT16	R
3	Current I_0	% x 10	UINT16	R
4	Voltage U_{12}	% x 10	UINT16	R
5	Voltage U_{23}	% x 10	UINT16	R
6	Voltage U_{31}	% x 10	UINT16	R
7	Voltage U_1	% x 10	UINT16	R
8	Voltage U_2	% x 10	UINT16	R
9	Voltage U_3	% x 10	UINT16	R
10	Voltage U_0	% x 10	UINT16	R
11	Phase angle I_1	° x 10	INT16	R
12	Phase angle I_2	° x 10	INT16	R
13	Phase angle I_3	° x 10	INT16	R
14	Phase angle I_0	° x 10	INT16	R
15	Phase angle U_{12}	° x 10	INT16	R
16	Phase angle U_{23}	° x 10	INT16	R
17	Phase angle U_{31}	° x 10	INT16	R
18	Phase angle U_1	° x 10	INT16	R
19	Phase angle U_2	° x 10	INT16	R
20	Phase angle U_3	° x 10	INT16	R
21	Phase angle U_0	° x 10	INT16	R
22	Apparent power S_1	% x 10	INT16	R
23	Active power P_1	% x 10	INT16	R
24	Reactive power Q_1	% x 10	INT16	R
25	Power factor PF_1	x1000	INT16	R

26	Frequency	Hz x100	UINT16	R
27	Apparent power S_2	% x 10	INT16	R
28	Active power P_2	% x 10	INT16	R
29	Reactive power Q_2	% x 10	INT16	R
30	Power factor PF_2	x1000	INT16	R
31	Apparent power S_3	% x 10	INT16	R
32	Active power P_3	% x 10	INT16	R
33	Reactive power Q_3	% x 10	INT16	R
34	Power factor PF_3	x1000	INT16	R
35	Current I_p (positive sequence)	% x 10	UINT16	R
36	Current I_n (negative sequence)	% x 10	UINT16	R
37	Phase angle I_p (positive sequence)	° x 10	INT16	R
38	Phase angle I_n (negative sequence)	° x 10	INT16	R
39	Current I_1 channel 2	% x 10	UINT16	R
40	Current I_2 channel 2	% x 10	UINT16	R
41	Current I_3 channel 2	% x 10	UINT16	R
42	Current I_0 channel 2	% x 10	UINT16	R
43	Phase angle I_1 channel 2	° x 10	INT16	R
44	Phase angle I_2 channel 2	° x 10	INT16	R
45	Phase angle I_3 channel 2	° x 10	INT16	R
46	Phase angle I_0 channel 2	° x 10	INT16	R
47	Current I_p (positive sequence) channel 2	% x 10	UINT16	R
48	Current I_n (negative sequence) channel 2	% x 10	UINT16	R
49	Phase angle I_p (positive sequence) channel 2	° x 10	INT16	R
50	Phase angle I_n (negative sequence) channel 2	° x 10	INT16	R
51-52	Active import energy	kWh	UINT32	R
53-54	Active export energy	kWh	UINT32	R
55-56	Reactive import energy	kVArh	UINT32	R
57-58	Reactive export energy	kVArh	UINT32	R

The second group of registers (Table 7.1.4) stores all the measured data in absolute values without any scaling using floating point data type.

Table 7.1.4 Primary values in float format. The data can be read using Modbus FC4.

Address (Dec)	Description	Units	Data type	Access
100	Current I_1	A	FLOAT	R
102	Current I_2	A	FLOAT	R
104	Current I_3	A	FLOAT	R
106	Current I_0	A	FLOAT	R

108	Voltage U_1	V	FLOAT	R
110	Voltage U_2	V	FLOAT	R
112	Voltage U_3	V	FLOAT	R
114	Voltage U_0	V	FLOAT	R
116	Voltage U_{12}	V	FLOAT	R
118	Voltage U_{23}	V	FLOAT	R
120	Voltage U_{31}	V	FLOAT	R
122	Active power P_1	kW	FLOAT	R
124	Active power P_2	kW	FLOAT	R
126	Active power P_3	kW	FLOAT	R
128	Total active power of three phases	kW	FLOAT	R
130	Reactive power Q_1	kVAr	FLOAT	R
132	Reactive power Q_2	kVAr	FLOAT	R
134	Reactive power Q_3	kVAr	FLOAT	R
136	Total reactive power of three phases	kVAr	FLOAT	R
138	Apparent power S_1	kVA	FLOAT	R
140	Apparent power S_2	kVA	FLOAT	R
142	Apparent power S_3	kVA	FLOAT	R
144	Total apparent power of three phases	kVA	FLOAT	R
146	Power factor PF_1	-	FLOAT	R
148	Power factor PF_2	-	FLOAT	R
150	Power factor PF_3	-	FLOAT	R
152	Total power factor of three phases	-	FLOAT	R
154	Frequency	Hz	FLOAT	R
156	Phase angle I_1	°	FLOAT	R
158	Phase angle I_2	°	FLOAT	R

160	Phase angle I_3	°	FLOAT	R
162	Phase angle I_0	°	FLOAT	R
164	Phase angle U_1	°	FLOAT	R
166	Phase angle U_2	°	FLOAT	R
168	Phase angle U_3	°	FLOAT	R
170	Phase angle U_0	°	FLOAT	R
172	Phase angle U_{12}	°	FLOAT	R
174	Phase angle U_{23}	°	FLOAT	R
176	Phase angle U_{31}	°	FLOAT	R
178	Current I_p (positive sequence)	A	FLOAT	R
180	Phase angle I_p (positive sequence)	°	FLOAT	R
182	Current I_n (negative sequence)	A	FLOAT	R
184	Phase angle I_n (negative sequence)	°	FLOAT	R
186	Current I_1 channel 2	A	FLOAT	R
188	Current I_2 channel 2	A	FLOAT	R
190	Current I_3 channel 2	A	FLOAT	R
192	Current I_0 channel 2	A	FLOAT	R
194	Phase angle I_1 channel 2	°	FLOAT	R
196	Phase angle I_2 channel 2	°	FLOAT	R
198	Phase angle I_3 channel 2	°	FLOAT	R
200	Phase angle I_0 channel 2	°	FLOAT	R
202	Current I_p (positive sequence) channel 2	A	FLOAT	R
204	Phase angle I_p (positive sequence) channel 2	°	FLOAT	R
206	Current I_n (negative sequence) channel 2	A	FLOAT	R
208	Phase angle I_n (negative sequence) channel 2	°	FLOAT	R

The third group of the measured values (Table 7.1.5) stores data in the same format as the second group. However, this group data are updated only at the first moment after detecting a fault. Even if measurements change after the

initial fault moment, the recorded data would not change.

Table 7.1.5 Primary values recorded during a fault in float format. The data can be read using Modbus FC4.

Address (Dec)	Description	Units	Data type	Access
300	Current I_1	A	FLOAT	R
302	Current I_2	A	FLOAT	R
304	Current I_3	A	FLOAT	R
306	Current I_0	A	FLOAT	R
308	Voltage U_1	V	FLOAT	R
310	Voltage U_2	V	FLOAT	R
312	Voltage U_3	V	FLOAT	R
314	Voltage U_0	V	FLOAT	R
316	Voltage U_{12}	V	FLOAT	R
318	Voltage U_{23}	V	FLOAT	R
320	Voltage U_{31}	V	FLOAT	R
322	Phase angle I_1	°	FLOAT	R
324	Phase angle I_2	°	FLOAT	R
326	Phase angle I_3	°	FLOAT	R
328	Phase angle I_0	°	FLOAT	R
330	Phase angle U_1	°	FLOAT	R
332	Phase angle U_2	°	FLOAT	R
334	Phase angle U_3	°	FLOAT	R
336	Phase angle U_0	°	FLOAT	R
338	Phase angle U_{12}	°	FLOAT	R
340	Phase angle U_{23}	°	FLOAT	R
342	Phase angle U_{31}	°	FLOAT	R
344	Current I_1 channel 2	A	FLOAT	R
346	Current I_2 channel 2	A	FLOAT	R
348	Current I_3 channel 2	A	FLOAT	R
350	Current I_0 channel 2	A	FLOAT	R
352	Phase angle I_1 channel 2	°	FLOAT	R
354	Phase angle I_2 channel 2	°	FLOAT	R
356	Phase angle I_3 channel 2	°	FLOAT	R
358	Phase angle I_0 channel 2	°	FLOAT	R

7.2 IEC 60870-5-101 operational information

IEC 60870-5-101 (IEC101) is a communication protocol designed for telecontrol applications in power systems, enabling communication between a master station and slave devices (e.g., Remote Terminal Units or RTUs). The implementation of IEC101 protocol allows for a data transfer to be initiated only by a master (unbalanced mode).

IOMod FPI via IEC101 protocol transmits various fault status and measurement signals in a standardized format. These signals are predefined in the IOMod and mapped to corresponding Information Object Addresses (IOA) (Table 7.2.1).

The protocol distinguishes between **Type Identifiers (TI)**, which according to the standard defines format, structure and type of the data being sent. The status and measurement signals are assigned to four different Type Identifiers: 7, 13, 30 and 36.

Time synchronization is critical for logging events. To synchronize time, the master sends a Time Sync command C_CS_NA_1 (103) with Cause of Transmission (COT) 6. According to the IEC 60870-5-101 protocol specification, time

synchronization can be performed for multiple devices using broadcast messages. A master device sends a broadcast timesync command with a broadcast link address. This ensures consistent time-stamping for event recording and fault detection across the network.

All the fault status signals are assigned to TI 30, which is named – "Single Point Information with Time Tag". TI 30 is designed for transferring the binary status of a single element, e.g. as to whether a circuit breaker is open or closed, along with a timestamp. In the context of IOMod FPI signals with TI 30 are sent by the IOMod after the change of the binary fault statuses adding the timestamp, which provides the time at which a fault status changed.

All the measurements are represented in absolute values without any scaling and using standard units. Almost every measurement can be sent using both 13 ("measured value, short floating-point number") and 36 ("measured value, short floating-point number with time tag CP56Time2a") Type Identifiers. The only exception is energy measurements which are going to be discussed later. The signals assigned to both type identifiers send measurement values using exactly the same data type, i.e. short floating point data type. The only difference in the data format of both type identifiers is that in case of the TI 36 timestamps are added at the end of each data object. The signals assigned to TI 36 are designed for spontaneous data transmission, which is initiated by the change of value. The timestamps added to the values being sent stores the time at which value has changed. The measurements which are sent with TI 13 signals are not marked with timestamps. This is because these signals are not intended for spontaneous transmission upon a change, but rather are to be polled by a controlling (master) station. All energy measurements are assigned to the signals with TI 7, which stands for "bitstring of 32 bit". The necessity in other data formats for the energy measurements comes from the fact that they are saved in 32-bit unsigned integer data type. The usage of integer type instead of float ensures better precision.

Table 7.2.1 List of status and measurement signals.

IOA	Description	Units	TI
0	Instantaneous overcurrent function (50) operated	-	30 (M_SP_TB_1)
1	Instantaneous overcurrent earth fault function (50N) operated	-	30 (M_SP_TB_1)
2	Overcurrent function (67) direction A operated	-	30 (M_SP_TB_1)
3	Overcurrent function (67) direction B operated	-	30 (M_SP_TB_1)
4	Earth fault (67N) direction A operated	-	30 (M_SP_TB_1)
5	Earth fault (67N) direction B operated	-	30 (M_SP_TB_1)
6	Overcurrent fault in phase L ₁	-	30 (M_SP_TB_1)
7	Overcurrent fault in phase L ₂	-	30 (M_SP_TB_1)
8	Overcurrent fault in phase L ₃	-	30 (M_SP_TB_1)
9	Residual overvoltage (59N) operated	-	30 (M_SP_TB_1)
10	Instantaneous overcurrent function (50) pickup	-	30 (M_SP_TB_1)
11	Instantaneous overcurrent earth fault function (50N) pickup	-	30 (M_SP_TB_1)
12	Directional overcurrent function (67) pickup	-	30 (M_SP_TB_1)
13	Directional earth fault function (67N) pickup	-	30 (M_SP_TB_1)
14	Blocking by 2nd harmonic active	-	30 (M_SP_TB_1)
15	Residual overvoltage (59N) pickup	-	30 (M_SP_TB_1)
16	Overvoltage (59) warning	-	30 (M_SP_TB_1)

17	Overvoltage (59) alarm	-	30 (M_SP_TB_1)
18	Undervoltage (27) warning	-	30 (M_SP_TB_1)
19	Undervoltage (27) alarm	-	30 (M_SP_TB_1)
20	Active power in phase L ₁ direction A	-	30 (M_SP_TB_1)
21	Active power in phase L ₁ direction B	-	30 (M_SP_TB_1)
22	Active power in phase L ₂ direction A	-	30 (M_SP_TB_1)
23	Active power in phase L ₂ direction B	-	30 (M_SP_TB_1)
24	Active power in phase L ₃ direction A	-	30 (M_SP_TB_1)
25	Active power in phase L ₃ direction B	-	30 (M_SP_TB_1)
26	Reverse phase rotation	-	30 (M_SP_TB_1)
27	Time inverse overcurrent earth fault function (51N) pickup	-	30 (M_SP_TB_1)
28	Time inverse overcurrent earth fault function (51N) operated	-	30 (M_SP_TB_1)
29	Reserved	-	30 (M_SP_TB_1)
30	Reserved	-	30 (M_SP_TB_1)
31	Reserved	-	30 (M_SP_TB_1)
32	Instantaneous overcurrent function (50) operated in channel 2	-	30 (M_SP_TB_1)
33	Instantaneous overcurrent earth fault function (50N) operated in channel 2	-	30 (M_SP_TB_1)
34	Time inverse overcurrent function (51) operated in channel 2	-	30 (M_SP_TB_1)
35	Time inverse overcurrent earth fault function (51N) operated in channel 2	-	30 (M_SP_TB_1)
36	Overcurrent fault in phase L ₁ of channel 2	-	30 (M_SP_TB_1)
37	Overcurrent fault in phase L ₂ of channel 2	-	30 (M_SP_TB_1)
38	Overcurrent fault in phase L ₃ of channel 2	-	30 (M_SP_TB_1)
39	Instantaneous overcurrent function (50) pickup in channel 2	-	30 (M_SP_TB_1)
40	Instantaneous overcurrent earth fault function (50N) pickup in channel 2	-	30 (M_SP_TB_1)
41	Time inverse overcurrent function (51) pickup in channel 2	-	30 (M_SP_TB_1)
42	Time inverse overcurrent earth fault function (51N) pickup in channel 2	-	30 (M_SP_TB_1)

43	Blocking by 2nd harmonic active in channel 2	-	30 (M_SP_TB_1)
100	Current I_1	A	13 (M_ME_NC_1)
101	Current I_2	A	13 (M_ME_NC_1)
102	Current I_3	A	13 (M_ME_NC_1)
103	Current I_0	A	13 (M_ME_NC_1)
104	Voltage U_1	V	13 (M_ME_NC_1)
105	Voltage U_2	V	13 (M_ME_NC_1)
106	Voltage U_3	V	13 (M_ME_NC_1)
107	Voltage U_0	V	13 (M_ME_NC_1)
108	Voltage U_{12}	V	13 (M_ME_NC_1)
109	Voltage U_{23}	V	13 (M_ME_NC_1)
110	Voltage U_{31}	V	13 (M_ME_NC_1)
111	Active power P_1	kW	13 (M_ME_NC_1)
112	Active power P_2	kW	13 (M_ME_NC_1)
113	Active power P_3	kW	13 (M_ME_NC_1)
114	Total active power P	kW	13 (M_ME_NC_1)
115	Reactive power Q_1	kVAr	13 (M_ME_NC_1)
116	Reactive power Q_2	kVAr	13 (M_ME_NC_1)
117	Reactive power Q_3	kVAr	13 (M_ME_NC_1)
118	Total reactive power Q	kVAr	13 (M_ME_NC_1)
119	Apparent power S_1	kVA	13 (M_ME_NC_1)
120	Apparent power S_2	kVA	13 (M_ME_NC_1)
121	Apparent power S_3	kVA	13 (M_ME_NC_1)
122	Total apparent power	kVA	13 (M_ME_NC_1)
123	Power factor PF_1	-	13 (M_ME_NC_1)

124	Power factor PF_2	-	13 (M_ME_NC_1)
125	Power factor PF_3	-	13 (M_ME_NC_1)
126	Total power factor PF	-	13 (M_ME_NC_1)
127	Frequency	Hz	13 (M_ME_NC_1)
128	Phase angle I_1	°	13 (M_ME_NC_1)
129	Phase angle I_2	°	13 (M_ME_NC_1)
130	Phase angle I_3	°	13 (M_ME_NC_1)
131	Phase angle I_0	°	13 (M_ME_NC_1)
132	Phase angle U_1	°	13 (M_ME_NC_1)
133	Phase angle U_2	°	13 (M_ME_NC_1)
134	Phase angle U_3	°	13 (M_ME_NC_1)
135	Phase angle U_0	°	13 (M_ME_NC_1)
136	Phase angle U_{12}	°	13 (M_ME_NC_1)
137	Phase angle U_{23}	°	13 (M_ME_NC_1)
138	Phase angle U_{31}	°	13 (M_ME_NC_1)
139	Current I_p (positive sequence)	A	13 (M_ME_NC_1)
140	Phase angle I_p (positive sequence)	°	13 (M_ME_NC_1)
141	Current I_n (negative sequence)	A	13 (M_ME_NC_1)
142	Phase angle I_n (negative sequence)	°	13 (M_ME_NC_1)
143	Current I_1 channel 2	A	13 (M_ME_NC_1)
144	Current I_2 channel 2	A	13 (M_ME_NC_1)
145	Current I_3 channel 2	A	13 (M_ME_NC_1)
146	Current I_0 channel 2	A	13 (M_ME_NC_1)
147	Phase angle I_1 channel 2	°	13 (M_ME_NC_1)
148	Phase angle I_2 channel 2	°	13 (M_ME_NC_1)
149	Phase angle I_3 channel 2	°	13 (M_ME_NC_1)

150	Phase angle I_0 channel 2	°	13 (M_ME_NC_1)
151	Current I_p (positive sequence) channel 2	A	13 (M_ME_NC_1)
152	Phase angle I_p (positive sequence) channel 2	°	13 (M_ME_NC_1)
153	Current I_n (negative sequence) channel 2	A	13 (M_ME_NC_1)
154	Phase angle I_n (negative sequence) channel 2	°	13 (M_ME_NC_1)
300	Current I_1	A	36 (M_ME_TF_1)
301	Current I_2	A	36 (M_ME_TF_1)
302	Current I_3	A	36 (M_ME_TF_1)
303	Current I_0	A	36 (M_ME_TF_1)
304	Phase voltage U_1	V	36 (M_ME_TF_1)
305	Phase voltage U_2	V	36 (M_ME_TF_1)
306	Phase voltage U_3	V	36 (M_ME_TF_1)
307	Phase voltage U_0	V	36 (M_ME_TF_1)
308	Line voltage U_{12}	V	36 (M_ME_TF_1)
309	Line voltage U_{23}	V	36 (M_ME_TF_1)
310	Line voltage U_{31}	V	36 (M_ME_TF_1)
311	Phase angle I_1	°	36 (M_ME_TF_1)
312	Phase angle I_2	°	36 (M_ME_TF_1)
313	Phase angle I_3	°	36 (M_ME_TF_1)
314	Phase angle I_0	°	36 (M_ME_TF_1)
315	Phase angle U_1	°	36 (M_ME_TF_1)
316	Phase angle U_2	°	36 (M_ME_TF_1)
317	Phase angle U_3	°	36 (M_ME_TF_1)
318	Phase angle U_0	°	36 (M_ME_TF_1)

319	Phase angle U_{12}	°	36 (M_ME_TF_1)
320	Phase angle U_{23}	°	36 (M_ME_TF_1)
321	Phase angle U_{31}	°	36 (M_ME_TF_1)
322	Current I_1 channel 2	A	36 (M_ME_TF_1)
323	Current I_2 channel 2	A	36 (M_ME_TF_1)
324	Current I_3 channel 2	A	36 (M_ME_TF_1)
325	Current I_0 channel 2	A	36 (M_ME_TF_1)
326	Phase angle I_1 channel 2	°	36 (M_ME_TF_1)
327	Phase angle I_2 channel 2	°	36 (M_ME_TF_1)
328	Phase angle I_3 channel 2	°	36 (M_ME_TF_1)
329	Phase angle I_0 channel 2	°	36 (M_ME_TF_1)
400	Active import energy	kWh	7 (M_BO_NA_1)
401	Active export energy	kWh	7 (M_BO_NA_1)
402	Reactive import energy	kVArh	7 (M_BO_NA_1)
403	Reactive export energy	kVArh	7 (M_BO_NA_1)

In addition to status and measurement signals, in the context of IEC 60870-5-101 protocol IMod FPI supports a single command signal (Table 7.2.2), which is "Clear Faults" (IOA 250). The command allows for a controlling station to reset all fault statuses of IMod FPI by means of one signal. After receiving the command the statuses of all fault detection functions are going to switch to "not detected".

Table 7.2.2 List of command signals.

IOA	Description	Units	TI
250	Clear faults	-	45 (C_SC_NA_1)

7.3 IEC 60870-5-103 operational information

IEC 60870-5-103 (IEC103) is a communication protocol specifically designed to standardize communication between control system devices and protection equipment in substations. Similarly to IEC 60870-5-101 (IEC101) protocol IEC103 supports both balanced (stations can transmit at any time) and unbalanced (primary station controls the transmission of the secondary stations) transmission modes.

Time synchronization is critical for logging events. To synchronize time, the master sends a Time Sync command with function 0 and Cause of Transmission (COT) 8. According to the IEC 60870-5-103 protocol specification, time synchronization can be performed for multiple devices using broadcast messages. For broadcast time synchronization, the master device sends a periodic signal with a time stamp to synchronize the system time of slave devices. If synchronization fails, devices default to their local system time until they successfully resynchronize.

IMod FPI defines 44 fault status signals (Table 7.3.1). All status signals are mapped to corresponding Information Object Addresses (IOA). Type Identification (TI) 1, which is named as "time-tagged message", is used for all fault status signals. TI 1 signals are designed for transferring double-point information (DPI) with a timestamp identifying the moment when a status has changed. Although double-point type is used, the fault statuses are binary, therefore only two out of four possible values are used: 1 (designating "OFF" state) and 2 (designating "ON" state). Such an approach provides more reliability, since two bites need to be modified when a change of a status occurs. Another thing which all

fault status signals have in common is the Function Type (FUN). The Function Type is the first octet of the Information Object Identifier, which is intended for protection functions identification. Traditionally it was regarded that each protection function is implemented in a separate device, therefore Function Type parameter identified the protection devices as well. On the other hand, the specific feature of IMod FPI is that a number of different fault detection functions are integrated in one device. Since IEC103 standard does not define such a device, all status signals are assigned to the private-range Function Type 253.

Table 7.3.1 List of status signals.

Type	FUN	INF	Description
1 (M_TTM_TA_3)	253	0	Instantaneous overcurrent function (50) operated
1 (M_TTM_TA_3)	253	1	Instantaneous overcurrent earth fault function (50N) operated
1 (M_TTM_TA_3)	253	2	Overcurrent function (67) direction A operated
1 (M_TTM_TA_3)	253	3	Overcurrent function (67) direction B operated
1 (M_TTM_TA_3)	253	4	Earth fault (67N) direction A operated
1 (M_TTM_TA_3)	253	5	Earth fault (67N) direction B operated
1 (M_TTM_TA_3)	253	6	Overcurrent fault in phase L ₁
1 (M_TTM_TA_3)	253	7	Overcurrent fault in phase L ₂
1 (M_TTM_TA_3)	253	8	Overcurrent fault in phase L ₃
1 (M_TTM_TA_3)	253	9	Residual overvoltage (59N) operated
1 (M_TTM_TA_3)	253	10	Instantaneous overcurrent function (50) pickup
1 (M_TTM_TA_3)	253	11	Instantaneous overcurrent earth fault function (50N) pickup
1 (M_TTM_TA_3)	253	12	Directional overcurrent function (67) pickup
1 (M_TTM_TA_3)	253	13	Directional earth fault function (67N) pickup
1 (M_TTM_TA_3)	253	14	Blocking by 2nd harmonic active
1 (M_TTM_TA_3)	253	15	Residual overvoltage (59N) pickup
1 (M_TTM_TA_3)	253	16	Overvoltage (59) warning
1 (M_TTM_TA_3)	253	17	Overvoltage (59) alarm
1 (M_TTM_TA_3)	253	18	Undervoltage (27) warning
1 (M_TTM_TA_3)	253	19	Undervoltage (27) alarm
1 (M_TTM_TA_3)	253	20	Active power in phase L ₁ direction A
1 (M_TTM_TA_3)	253	21	Active power in phase L ₁ direction B
1 (M_TTM_TA_3)	253	22	Active power in phase L ₂ direction A
1 (M_TTM_TA_3)	253	23	Active power in phase L ₂ direction B
1 (M_TTM_TA_3)	253	24	Active power in phase L ₃ direction A
1 (M_TTM_TA_3)	253	25	Active power in phase L ₃ direction B
1 (M_TTM_TA_3)	253	26	Reverse phase rotation
1 (M_TTM_TA_3)	253	27	Time inverse overcurrent earth fault function (51N) pickup

1 (M_TTM_TA_3)	253	28	Time inverse overcurrent earth fault function (51N) operated
1 (M_TTM_TA_3)	253	29	Reserved
1 (M_TTM_TA_3)	253	30	Reserved
1 (M_TTM_TA_3)	253	31	Reserved
1 (M_TTM_TA_3)	253	32	Instantaneous overcurrent function (50) operated in channel 2
1 (M_TTM_TA_3)	253	33	Instantaneous overcurrent earth fault function (50N) operated in channel 2
1 (M_TTM_TA_3)	253	34	Time inverse overcurrent function (51) operated in channel 2
1 (M_TTM_TA_3)	253	35	Time inverse overcurrent earth fault function (51N) operated in channel 2
1 (M_TTM_TA_3)	253	36	Overcurrent fault in phase L ₁ of channel 2
1 (M_TTM_TA_3)	253	37	Overcurrent fault in phase L ₂ of channel 2
1 (M_TTM_TA_3)	253	38	Overcurrent fault in phase L ₃ of channel 2
1 (M_TTM_TA_3)	253	39	Instantaneous overcurrent function (50) pickup in channel 2
1 (M_TTM_TA_3)	253	40	Instantaneous overcurrent earth fault function (50N) pickup in channel 2
1 (M_TTM_TA_3)	253	41	Time inverse overcurrent function (51) pickup in channel 2
1 (M_TTM_TA_3)	253	42	Time inverse overcurrent earth fault function (51N) pickup in channel 2
1 (M_TTM_TA_3)	253	43	Blocking by 2nd harmonic active in channel 2

In addition to status signals, in the context of IEC 60870-5-103 protocol IMod FPI supports a single command signal (Table 7.3.2), which is "Clear Faults" (IOA 250). The command allows for a controlling station to reset all fault statuses of IMod FPI by means of one signal. After receiving the command, the statuses of all fault detection functions are going to switch to "not detected". The Function Type of the signal is 254, which signifies the "generic function type". The Type Identification 20 is named "general command".

Table 7.3.2 List of command signals.

Type	FUN	INF	Description
20 (C_GRC_NA_3)	254	250	Clear faults

All measurement data are assigned to certain sets (Table 7.3.3, Table 7.3.4). Depending on the connection mode three or four sets are defined. In the case of 3I3U connection mode there are more data, thus it has four sets of data. Since in the 3I3I connection mode only current measurements are performed, it has less values to send, therefore only three data sets are defined. Type Identification 9, which also is called "Measurands II", is used for all measurement signals. Each set of measurements has the unique Information Number (INF).

Table 7.3.3 Data sets for 3I3U connection mode.

Set Nr.	Type	FUN	INF	Quantity of Data	Information elements (measurands)
1	9	253	148	9	I ₁ , I ₂ , I ₃ , U ₁ , U ₂ , U ₃ , P, Q, f
2	9	253	149	23	I ₁ , I ₂ , I ₃ , I ₄ , U ₁ , U ₂ , U ₃ , U ₄ , P ₁ , P ₂ , P ₃ , Q ₁ , Q ₂ , Q ₃ , S ₁ , S ₂ , S ₃ , PF ₁ , PF ₂ , PF ₃ , U ₁₂ ^(angle) , U ₂₃ ^(angle) , U ₁₃ ^(angle)

3	9	253	150	60	$I_1, I_2, I_3, I_N, U_1, U_2, U_3, U_N, P_1, P_2, P_3, Q_1, Q_2, Q_3, S_1, S_2, S_3, PF_1, PF_2, PF_3, U_{12}, U_{23}, U_{13}, f, THD_{U_1}, THD_{U_2}, THD_{U_3}, THD_{I_1}, THD_{I_2}, THD_{I_3}, I_1^{(h2)}, I_1^{(h3)}, I_1^{(h5)}, I_1^{(h7)}, I_1^{(h9)}, I_2^{(h2)}, I_2^{(h3)}, I_2^{(h5)}, I_2^{(h7)}, I_2^{(h9)}, I_3^{(h2)}, I_3^{(h3)}, I_3^{(h5)}, I_3^{(h7)}, I_3^{(h9)}, U_1^{(h2)}, U_1^{(h3)}, U_1^{(h5)}, U_1^{(h7)}, U_1^{(h9)}, U_2^{(h2)}, U_2^{(h3)}, U_2^{(h5)}, U_2^{(h7)}, U_2^{(h9)}, U_3^{(h2)}, U_3^{(h3)}, U_3^{(h5)}, U_3^{(h7)}, U_3^{(h9)}$
4	9	253	151	54	$I_1, I_2, I_3, I_N, U_{12}, U_{23}, U_{13}, U_N, S, P, Q, PF, THD_{U_1}, THD_{U_2}, THD_{U_3}, THD_{I_1}, THD_{I_2}, THD_{I_3}, I_1^{(h3)}, I_1^{(h5)}, I_1^{(h7)}, I_1^{(h9)}, I_2^{(h3)}, I_2^{(h5)}, I_2^{(h7)}, I_2^{(h9)}, I_3^{(h3)}, I_3^{(h5)}, I_3^{(h7)}, I_3^{(h9)}, U_1^{(h3)}, U_1^{(h5)}, U_1^{(h7)}, U_1^{(h9)}, U_2^{(h3)}, U_2^{(h5)}, U_2^{(h7)}, U_2^{(h9)}, U_3^{(h3)}, U_3^{(h5)}, U_3^{(h7)}, U_3^{(h9)}, P_1, P_2, P_3, Q_1, Q_2, Q_3, U_1^{(angle)}, U_2^{(angle)}, U_3^{(angle)}, U_1, U_2, U_3$

Table 7.3.4 Data sets for 3I3I connection mode.

Set Nr.	Type	FUN	INF	Quantity of Data	Information elements (measurands)
1	9	253	148	7	$I_1^{(ch1)}, I_2^{(ch1)}, I_3^{(ch1)}, I_1^{(ch2)}, I_2^{(ch2)}, I_3^{(ch2)}, f$
2	9	253	149	8	$I_1^{(ch1)}, I_2^{(ch1)}, I_3^{(ch1)}, I_4^{(ch1)}, I_1^{(ch2)}, I_2^{(ch2)}, I_3^{(ch2)}, I_4^{(ch2)}$
3	9	253	150	45	$I_1^{(ch1)}, I_2^{(ch1)}, I_3^{(ch1)}, I_0^{(ch1)}, I_1^{(ch2)}, I_2^{(ch2)}, I_3^{(ch2)}, I_0^{(ch2)}, f, THD_{I_1}^{(ch1)}, THD_{I_2}^{(ch1)}, THD_{I_3}^{(ch1)}, I_1^{(h3, ch1)}, I_1^{(h5, ch1)}, I_1^{(h7, ch1)}, I_1^{(h9, ch1)}, I_2^{(h3, ch1)}, I_2^{(h5, ch1)}, I_2^{(h7, ch1)}, I_2^{(h9, ch1)}, I_3^{(h3, ch1)}, I_3^{(h5, ch1)}, I_3^{(h7, ch1)}, I_3^{(h9, ch1)}, THD_{I_1}^{(ch2)}, THD_{I_2}^{(ch2)}, THD_{I_3}^{(ch2)}, I_1^{(h3, ch2)}, I_1^{(h5, ch2)}, I_1^{(h7, ch2)}, I_1^{(h9, ch2)}, I_2^{(h3, ch2)}, I_2^{(h5, ch2)}, I_2^{(h7, ch2)}, I_2^{(h9, ch2)}, I_3^{(h3, ch2)}, I_3^{(h5, ch2)}, I_3^{(h7, ch2)}, I_3^{(h9, ch2)}$

The certain set of measurements can be configured in IOMod Utility General settings (see Table 5.1.1, Fig 7.3.1).

Measurands set

1

Scale factor

1.2

Fig. 7.3.1 IOMod Utility General settings IEC 60870-5-103 protocol parameters

Type 9 signals allocate only 13 bits for measurement values, which is not enough for float values to be transferred. For that reason, all measurement data are being scaled. However, not all values are scaled the same. All currents, voltages and power measurements are scaled using the same algorithm. The range of the maximum and the minimum measurement values, which can be transferred with IEC103 protocol is calculated by multiplying the nominal value by scale factor:

$$MMV = SF \cdot NV \quad (7.3.1)$$

- MMV – maximum measurement value;
- NV – nominal value;
- SF – scale factor;

The scale factor of most measurements can be selected in IOMod Utility General settings (Table 5.1.1, Fig. 7.3.1). The maximum measurement value (MMV) is only the upper limit of the allowed range. The full allowed range goes from -MMV up to +MMV. Since the first bit is used to denote the sign, the maximum absolute value, which can be sent via IEC 60870-5-103 communication protocol is $2^{12} = 4096$. The MMV is mapped to this value, so that if the measured value is equal to the MMV, 4096 is going to be sent to a controlling station via IEC103 protocol. If a measurement value exceeds MMV, then the overflow is going to be indicated by the signal and 4096 is going to be sent. If a measured value is inside of the allowed range, then the scaled value, which is going to be sent by means of IEC103 signal, is calculated by multiplying it by 4096 and dividing it by the maximum measurement value:

$$SV = \frac{MV \cdot 4096}{MMV}, \text{ where } -MMV \leq MV \leq +MMV \quad (7.3.2)$$

- SV – scaled value, which is going to be sent by means of IEC103 protocol;
- MV – measured value, which must be in the allowed range;
- MMV – maximum measurement value;

In the special case, where measured value is equal to the nominal value the scaled value formula can be simplified as:

$$SV = \frac{NV \cdot 4096}{SF \cdot NV} = \frac{4096}{SF} \quad (7.3.3)$$

The scaled values of other measurands are calculated by using different scaling techniques. The scaled frequency is calculated by multiplying the measured frequency by 50. All angle measurements are scaled by a factor of 10.