

14 IEC 60870-5-10X

- 14.1 Introduction
- 14.2 IEC 60870-5-101 Master
- 14.3 IEC 60870-5-101 Slave
- 14.4 IEC 60870-5-103 Master
- 14.5 IEC 60870-5-104 Master
- 14.6 IEC 60870-5-104 Slave

14.1 Introduction

IEC 60870 part 5 is one of the IEC 60870 set of standards which define systems used for telecontrol (supervisory control and data acquisition) in electrical engineering and power system automation applications. Part 5 provides a communication profile for sending basic telecontrol messages between two systems, which uses permanent directly connected data circuits between the systems. The IEC Technical Committee 57 (Working Group 03) has developed a protocol standard for telecontrol, teleprotection, and associated telecommunications for electric power systems. The result of this work is IEC 60870-5. Five documents specify the base IEC 60870-5:

- IEC 60870-5-1 Transmission Frame Formats
- IEC 60870-5-2 Data Link Transmission Services
- IEC 60870-5-3 General Structure of Application Data
- IEC 60870-5-4 Definition and Coding of Information Elements
- IEC 60870-5-5 Basic Application Functions
- IEC 60870-5-6 Guidelines for conformance testing for the IEC 60870-5 companion standards
- IEC TS 60870-5-7 Security extensions to IEC 60870-5-101 and IEC 60870-5-104 protocols (applying IEC 62351)

The IEC Technical Committee 57 has also generated companion standards:

- IEC 60870-5-101 Transmission Protocols - companion standards especially for basic telecontrol tasks
- IEC 60870-5-102 Transmission Protocols - Companion standard for the transmission of integrated totals in electric power systems (this standard is not widely used)
- IEC 60870-5-103 Transmission Protocols - Companion standard for the informative interface of protection equipment
- IEC 60870-5-104 Transmission Protocols - Network access for IEC 60870-5-101 using standard transport profiles
- IEC TS 60870-5-601 Transmission protocols - Conformance test cases for the IEC 60870-5-101 companion standard
- IEC TS 60870-5-604 Conformance test cases for the IEC 60870-5-104 companion standard


IEC 60870-5-101/102/103/104 are companion standards generated for basic telecontrol tasks, transmission of integrated totals, data exchange from protection equipment & network access of IEC101 respectively.

Source: https://en.wikipedia.org/wiki/IEC_60870-5

14.2 IEC 60870-5-101 Master

The IEC 60870-5-101 protocol is a companion standard for power system monitoring, control associated communications for telecontrol, teleprotection, and associated telecommunications for electric power systems. Standard IEC 60870-5-101 was prepared by IEC technical committee 57 (Power system control and associated communications).

Standard IEC 60870-5-101 defines an **Application Service Data Unit (ASDU)** Figure below). In ASDU there is an ASDU identifier(with the type of ASDU in it) and information objects.




IEC 60870-5-101 ASDU structure

Common Address of ASDU Defines the stations' address and can be configured in Devices asdu_address field for source and *Signals* common_address field for the destination.

Information Object Address Used as destination object address in the control direction and as source object address in monitor direction can be configured in Signals info_address field.

Standard IEC 60870-5-101 transmission frames are separated into 3 different types: **frame with variable length**, **frame with fixed length**, and **single control characters**



IEC 60870-5-101 ASDU structure

Control field provides information about the message direction, type of service, and checksum.

Address field specifies the link address which points to the message's destination. WCC Lite supports IEC 60870-5--

101 Master protocol over a serial link (according to EIA RS485). Its full functionality list can be found in an IEC 60870-5-101 PID Interoperability List which can be downloaded separately from this user manual.

Configuring datapoints (master)

To use IEC 60870-5-101 Master in WCC Lite, it has to be configured via an Excel configuration. This configuration contains two Excel sheets where parameters have to be filled in Devices and Signals.

IEC 60870-5-101 master parameters for *Devices* tab

| Parameter | Type | Description | Required | Default value (when not specified) | Range | |
|--------------|---------|---|----------|---------------------------------------|---|-------|
| | | | | | Min | Max |
| name | string | User-friendly name for a device | Yes | | | |
| description | string | Description of a device | No | | | |
| device_alias | string | Alphanumeric string to identify a device | Yes | | | |
| enable | boolean | Enabling/disabling of a device | No | 1 | 0 | 1 |
| protocol | string | Protocol to be used | Yes | | IEC 60870-5-101 master | |
| device | string | Communication port | Yes | | PORT1 | PORT2 |
| baudrate | integer | Communication speed, baud/s | No | 9600 | 300, 600, 1200, 2400, 4800, 9600, 19200, 38400, 57600, 115200 | |
| databits | integer | Data bit count for communication | No | 8 | 6 | 9 |
| stopbits | integer | Stop bit count for communication | No | 1 | 1 | 2 |
| parity | string | Communication parity option | No | none | none, even, odd | |
| flowcontrol | string | | No | none | none | |
| link_address | integer | Destination address when in transmit and source address when broadcasting | Yes | | 0 | 65535 |
| link_size | integer | Link address size in bytes | No | 1 | 1 | 2 |

| | | | | | | |
|------------------------|---------|--|-----|------|---|-------|
| asdu_address | integer | Application Service Data Unit address | Yes | | 0 | 65535 |
| asdu_size | integer | Common address size in bytes | No | 1 | 1 | 3 |
| ioa_size | integer | Information object address (IOA) size in bytes | No | 2 | 1 | 3 |
| cot_size | integer | Cause of transmission (COT) size in bytes | No | 1 | 1 | 2 |
| time_sync_interval_sec | integer | Defines how often (in seconds) slave will request time synchronization. If greater than 0 - slave will request synchronizations, will reset the timer if the master did it earlier. If 0 - slave won't request timesyncs, but will allow them. If 1 - timesyncs are not supported - requests will be dropped. | No | 60 | | |
| gi_interval_sec | integer | Time frame between General Interrogation requests in seconds, if 0 requests are disabled | No | 300 | | |
| scan_rate_ms | integer | Polling interval in milliseconds. Time frame between two telegrams from master | No | 100 | | |
| timeout_ms | integer | Response timeout in milliseconds | No | 1000 | | |
| retry_count | integer | Number of retries of failed requests before announcing that device is in Error state | No | 1 | | |

IEC 60870-5-101 master parameters for Signals tab

| Parameter | Type | Description | Required | Default value (when not specified) | Range | |
|--------------|--------|---|----------|---------------------------------------|-------|-----|
| | | | | | Min | Max |
| signal_name | string | User-friendly signal name | Yes | | | |
| device_alias | string | Alphanumeric string to identify a device | Yes | | | |
| signal_alias | string | Unique alphanumeric name of the signal to be Yes used | Yes | | | |

| | | | | | | |
|---------------------|---------|---|--------------|---|---|---|
| source_device_alias | string | device_alias of a source device | For commands | | | |
| source_signal_alias | string | signal_alias of a source signal | For commands | | | |
| enable | boolean | Enabling/disabling of an individual signal | No | 1 | 0 | 1 |
| log | integer | Allow signal to be logged. If log is 0 signal will not be logged. If log is more than 0 signal will be logged | No | 0 | | |
| gi | boolean | Including/excluding (1 or 0) signal from General Interrogation | No | 0 | 0 | 1 |
| common_address | integer | Address of a destination device | Yes | | | |
| info_address | integer | Information object address | Yes | | | |
| data_type | integer | ASDU type identifier | Yes | | | |

IEC 60870-5-101 has an additional signal which can be configured to show communication status. It is used to indicate if the slave device has disconnected from master (WCC Lite). To configure such signal, two columns should be filled with particular values. To a newly created additional signal one should make **job_todo** equal to device_status and **tag_job_todo** equal to communication_status.

Debugging a IEC 60870-5-101 Master application

If configuration for IEC 60870-5-101 devices is set up, handler for protocol will start automatically. If the configuration is missing or contains errors, protocol will not start. It is done intentionally decrease unnecessary memory usage.

If IEC 60870-5-101 does not work properly (e.g. no communication between devices, data is corrupted, etc.), a user can launch a debug session from command line interface and find out why link is not functioning properly. To launch a debugging session, a user should stop *iec101-master* process and run *iec101-master* command with respective flags as shown in the table below.

Procedure for IEC 60870-5-101 master service debugging:

- **Step 1:** Service must be stopped by entering the following command into the wcc-lite:
/etc/init.d/iec101-master stop
- **Step 2:** After service is stopped it must be started with the preferred configuration file (JSON files found in /etc/ folder) and a debug level 7:**iec101-master -c /etc/iec101-master/iec101master.json -d7**
Additional output forming options described here: Command line arguments.
- **Step 3:** Once the problem is diagnosed normal operations can be resumed with the following command: **/etc/init.d/iec101-master start**

IEC 60870-5-101 command line debugging options

```
-h [ -help ] Display help information
-V [ -version ] Show version
-d<debug level> Set debugging level
-c [ -config ] Config path
-r [ -raw ] Show raw telegram data
-f [ -frame ] Show frame data
-R [ -readyfile ] Ready notification file
```

14.3 IEC 60870-5-101 Slave

Configuring datapoints (slave)

To use IEC 60870-5-101 Slave in WCC Lite, it has to be configured via an Excel configuration. This configuration contains two Excel sheets where parameters have to be filled in *Devices* and *Signals*.

IEC 60870-5-101 slave parameters for Devices tab

| Parameter | Type | Description | Required | Default value (when not specified) | Range | |
|--------------|---------|---|----------|---------------------------------------|---|-------|
| | | | | | Min | Max |
| name | string | User-friendly name for a device | Yes | | | |
| description | string | Description of a device | No | | | |
| device_alias | string | Alphanumeric string to identify a device | Yes | | | |
| enable | boolean | Enabling/disabling of a device | No | 1 | 0 | 1 |
| protocol | string | Protocol to be used | Yes | | IEC 60870-5-101 slave | |
| device | string | Communication port | Yes | | PORT1 | PORT2 |
| baudrate | integer | Communication speed, baud/s | No | 9600 | 300, 600, 1200, 2400, 4800, 9600, 19200, 38400, 57600, 115200 | |
| databits | integer | Data bit count for communication | No | 8 | 6 | 9 |
| stopbits | integer | Stop bit count for communication | No | 1 | 1 | 2 |
| parity | string | Communication parity option | No | none | none, even, odd | |
| flowcontrol | string | Number of requests, before link is considered lost (device status signals are changed) and reconnect attempt will be issued | No | none | none | |
| link_address | integer | Destination address when in transmit and source address when broadcasting | Yes | | 0 | 65535 |
| link_size | integer | Link address size in bytes | No | 1 | 1 | 2 |
| asdu_size | integer | Common address size in bytes | No | 1 | 1 | 3 |

| | | | | | | |
|--------------------|---------|---|-----|-----|---|---------|
| ioa_size | integer | Information object address (IOA) size in bytes | No | 2 | 1 | 3 |
| cot_size | integer | Cause of transmission (COT) size in bytes | No | 1 | 1 | 2 |
| time_sync | boolean | Allow time synchronization, 1 to enable and 0 to disable | No | 0 | 0 | 1 |
| message_size | integer | Maximum length of a message | Yes | | 0 | 255 |
| cache_size | integer | Maximum number of events to store in a buffer | No | 100 | 0 | 1000 |
| respond_delay | integer | Time in microseconds to wait before sending responses | Yes | | 0 | 1000000 |
| single_byte_ack | boolean | Use single character acknowledge, 1 to enable and 0 to disable | No | 0 | 0 | 1 |
| keep_alive_timeout | integer | Time interval in seconds before serial connection is considered offline | No | 60 | | |

keep_alive_timeout timer is used for connection tracker to display protocol status. This parameter has no effect on protocol functionality and is only used to track it's status in connection tracker.

IEC 60870-5-101 slave parameters for Signals tab

| Parameter | Type | Description | Required | Default value (when not specified) | Range | |
|-----------------------|---------|---|--------------|---------------------------------------|-------|-----|
| | | | | | Min | Max |
| signal_name | string | User-friendly signal name | Yes | | | |
| device_alias | string | Alphanumeric string to identify a device | Yes | | | |
| signal_alias | string | Unique alphanumeric name of the signal to be Yes used | Yes | | | |
| source_device_alias | string | device_alias of a source device | For commands | | | |
| source_signal_aliases | string | signal_alias of a source signal | For commands | | | |
| enable | boolean | Enabling/disabling of an individual signal | No | 1 | 0 | 1 |
| log | integer | Allow signal to be logged. If log is 0 signal will not be logged. If log is more than 0 signal will be logged | No | 0 | | |
| gi | boolean | Including/excluding (1 or 0) signal from General Interrogation | No | 0 | 0 | 1 |

| | | | | | | |
|----------------|---------|---------------------------------|-----|--|--|--|
| common_address | integer | Address of a destination device | Yes | | | |
| info_address | integer | Information object address | Yes | | | |
| data_type | integer | ASDU type identifier | Yes | | | |

IEC 608705101 has an additional signal which can be configured to show communication status. It is used to indicate if the slave device has disconnected from the master (WCC Lite). To configure such a signal, two columns should be filled with particular values. To a newly created additional signal, one should make **job_todo** equal to device_status and **tag_job_todo** equal to communication_status.

Debugging an IEC 60870-5-101 slave application

If the configuration for IEC 60870-5-101 devices is set up, the handler for the protocol will start automatically. If the configuration is missing or contains errors, the protocol will not start. It is done intentionally to decrease unnecessary memory usage.

If IEC 60870-5-101 does not work properly (e.g. no communication between devices, data is corrupted, etc.), a user can launch a debug session from the command-line interface and find out why the link is not functioning properly. To launch a debugging session, a user should stop the *iec101-slave* process and run the *iec101-slave* command with respective flags as shown in the table below.

Procedure for IEC 60870-5-101 slave service debugging:

- **Step 1:** Service must be stopped by entering the following command into the wcc-lite:
/etc/init.d/iec101-slave stop
- **Step 2:** After service is stopped it must be started with the preferred configuration file (JSON files found in /etc/ folder) and a debug level 7:**iec101-slave-c /etc/iec101-slave/iec101slave.json -d7**
Additional output forming options described here: Command line arguments.
- **Step 3:** Once the problem is diagnosed normal operations can be resumed with the following command: **/etc/init.d/iec101-slave start**

IEC 60870-5-101 command line debugging options

```
-h [ -help ] Display help information
-V [ -version ] Show version
-d<debug level> Set debugging level
-c [ -config ] Config path
-r [ -raw ] Show raw telegram data
-f [ -frame ] Show frame data
-R [ -readyfile ] Ready notification file
```

14.4 IEC 60870-5-103 Master

The IEC 60870-5-103 protocol is a companion standard for the informative interface of protection equipment. Standard IEC 60870-5-103 was prepared by IEC technical committee 57 (Power system control and associated communications). It is a companion standard for the basic standards in series IEC 60870-5:

Standard IEC 60870-5-103 defines communication between protection equipment and devices of a control system (supervisor or RTU) in a substation.

Standard IEC 60870-5-103 defines a multipoint communication protocol via which information can be exchanged between a control system (supervisor or RTU) and one or more protection devices. The control system is the master and the protection devices are the slaves. Each slave is identified by a unique address between 1 and 254. Address 255 is reserved for broadcast frames.

IEC 60870-5-103 Master

Configuring datapoints

WCC Lite supports IEC 60870-5-103 Master protocol over a serial link (according to EIA RS-485). Its full functionality list can be found in an IEC 60870-5-103 PID Interoperability List.

To use IEC 60870-5-103 Master in WCC Lite, it has to be configured via an Excel configuration. This configuration contains two Excel sheets where parameters have to be filled in - Devices and Signals.

IEC 60870-5-103 parameters for Devices tab

| Parameter | Type | Description | Required | Default value (when not specified) | Range | |
|--------------|---------|--|----------|---------------------------------------|---|-------|
| | | | | | Min | Max |
| name | string | User-friendly name for a device | Yes | | | |
| description | string | Description of a device | No | | | |
| device_alias | string | Alphanumeric string to identify a device | Yes | | | |
| enable | boolean | Enabling/disabling of a device | No | 1 | 0 | 1 |
| protocol | string | Protocol to be used | Yes | | IEC 60870-5-103 master | |
| device | string | Communication port | Yes | | PORT1 | PORT2 |
| baudrate | integer | Communication speed, baud/s | No | 9600 | 300, 600, 1200, 2400, 4800, 9600, 19200, 38400, 57600, 115200 | |
| databits | integer | Data bit count for communication | No | 8 | 8 | |
| stopbits | integer | Stop bit count for communication | No | 1 | 1 | 2 |
| parity | string | Communication parity option | No | none | none, even, odd | |

| | | | | | | |
|------------------------|---------|---|-----|------|------|-------|
| flowcontrol | string | Number of requests, before link is considered lost (device status signals are changed) and reconnect attempt will be issued | No | none | none | |
| link_address | integer | Destination address when in transmit and source address when broadcasting | Yes | | 0 | 65535 |
| asdu_address | integer | Application Service Data Unit address | Yes | | 0 | 65535 |
| time_sync_interval_sec | integer | Time frame between Time Synchronization requests in seconds | No | 60 | | |
| gi_interval_sec | integer | Time frame between General Interrogation requests in seconds, if 0 requests are disabled | No | 300 | | |
| scan_rate_ms | integer | Polling interval in milliseconds. Time frame between two telegrams from master | No | 100 | | |
| timeout_ms | integer | Response timeout in milliseconds | No | 1000 | | |
| serial_delay | integer | Communication device's serial delay in milliseconds. Time frame in which master station is not TX'ing after last RX byte | No | 50 | | |
| retry_count | integer | Number of retries of failed requests before announcing that device is in Error state | No | 3 | | |
| retry_delay_ms | integer | Time before the next retry in milliseconds | No | 500 | | |

IEC 60870-5-103 master parameters for Signals tab

| Parameter | Type | Description | Required | Default value (when not specified) | Range | |
|-----------------------|--------|---|--------------|---------------------------------------|-------|-----|
| | | | | | Min | Max |
| signal_name | string | User-friendly signal name | Yes | | | |
| device_alias | string | Alphanumeric string to identify a device | Yes | | | |
| signal_alias | string | Unique alphanumeric name of the signal to be Yes used | Yes | | | |
| source_device_alias | string | device_alias of a source device | For commands | | | |
| source_signal_aliases | string | signal_alias of a source signal | For commands | | | |

| | | | | | | |
|-------------------|---------|---|---------------------|-----|---|---|
| enable | boolean | Enabling/disabling of an individual signal | No | 1 | 0 | 1 |
| log | integer | Allow signal to be logged. If log is 0 signal will not be logged. If log is more than 0 signal will be logged | No | 0 | | |
| gi | boolean | Including/excluding (1 or 0) signal from General Interrogation | No | 0 | 0 | 1 |
| common_address | integer | Address of a destination device | Yes | | | |
| function | integer | Function number | No | 0 | | |
| info_address | integer | Information object address | Yes | | | |
| info_number | integer | Information number | Yes | | | |
| data_type | integer | ASDU type identifier | No | 0 | | |
| fleeting | boolean | Mark signal as fleeting type (1 or 0). Fleeting signals have to go to DPI::OFF after defined time | No | | 0 | 1 |
| normalise_time_ms | integer | Time in milliseconds between station receiving DPI::ON and automatically switching to DPI::OFF | If fleeting is used | 100 | | |

IEC 60870-5-103 has an additional signal which can be configured to show communication status. It is used to indicate if the slave device has disconnected from the master (WCC Lite). To configure such a signal, two columns should be filled with particular values. To a newly created additional signal, one should make **job_todo** equal to device_status and **tag_job_todo** equal to communication_status.

Debugging an IEC 60870-5-103 Master application

If the configuration for IEC 60870-5-103 devices is set up, the handler for the protocol will start automatically. If a configuration is missing or contains errors, the protocol will not start. It is done intentionally to decrease unnecessary memory usage.

If IEC 60870-5-103 does not work properly (e.g. no communication between devices, data is corrupted, etc.), a user can launch a debug session from the command-line interface and find out why the link is not functioning properly or use WCC Utility to do that.

To launch a debugging session, a user should stop the iec103-master process and run the iec103-master command with respective flags.

- Step 1: Service must be stopped by entering the following command into the wcc-lite:
/etc/init.d/iec103-master stop
- Step 2: After service is stopped it must be started with the preferred configuration file (JSON files found in /etc/ folder) and a debug level 7: **iec103-master -c /etc/iec103-master/iec103-master.json -d7**
- Step 3: Once the problem is diagnosed normal operations can be resumed with the following command:
/etc/init.d/iec103-master start


IEC 60870-5-103 command line debugging options


```
-h [ -help ] Display help information
-V [ -version ] Show version
-d<debug level> Set debugging level
-c [ -config ] Config path
-r [ -raw ] Show raw telegram data
-f [ -frame ] Show frame data
-R [ -readyfile ] Ready notification file
```


14.5 IEC 60870-5-104 Master

IEC 60870-5-104 protocol (in short IEC 104) is a part of IEC Telecontrol Equipment and Systems Standard IEC 60870-5 that provides a communication profile for sending basic telecontrol messages between two systems in electrical engineering and power system automation. Telecontrol means transmitting supervisory data and data acquisition requests for controlling power transmission grids.

IEC 104 provides network access to IEC 60870-5-101 (in short IEC 101) using standard transport profiles. In simple terms, it delivers IEC 101 messages as application data (L7) over TCP, usually port 2404. IEC 104 enables the communication between the control station and a substation via a standard TCP/IP network. The communication is based on the client-server model.

 To set up TLS connection for both IEC104 Master and Slave, refer to sections Excel configuration and Certificates. All keys and certificates should be provided in the PEM format.

 If no configuration is set up, IEC104 Master and Slave services are not started.

Configuring IEC 104 Master datapoints

To use IEC 60870-5-104 Master in WCC Lite, it has to be configured via an Excel configuration. This configuration contains two Excel sheets where parameters have to be filled in Devices and Signals.

IEC 60870-5-104 Master parameters for *Devices* tab

| Parameter | Type | Description | Required | Default value (when not specified) | Range | |
|------------------------|---------|--|----------|---------------------------------------|------------------------|-------|
| | | | | | Min | Max |
| name | string | User-friendly name for a device | Yes | | | |
| description | string | Description of a device | No | | | |
| device_alias | string | Alphanumeric string to identify a device | Yes | | | |
| enable | boolean | Enabling/disabling of a device | No | 1 | 0 | 1 |
| protocol | string | Protocol to be used | Yes | | IEC 60870-5-104 master | |
| asdu_address | integer | Application Service Data Unit address | Yes | | 0 | 65535 |
| asdu_size | integer | Common address size in bytes | No | 2 | 1 | 3 |
| time_sync_interval_sec | integer | Time frame between Time Synchronization requests in seconds | No | 60 | | |
| gi_interval_sec | integer | Time frame between General Interrogation requests in seconds. If 0 requests are disabled | No | 300 | | |
| port | integer | TCP port | Yes | | 0 | 65535 |

| | | | | | | |
|------------|---------|--|-----|----|---|-----|
| ioa_size | integer | Information object address (IOA) size in bytes | No | 3 | 1 | 3 |
| swt | integer | Send window (SWT) | Yes | | | |
| rwt | integer | Receive window (RWT) | Yes | | | |
| cot_size | integer | Cause of transmission (COT) size in bytes | No | 2 | 1 | 2 |
| ip | string | Host IP address (ipv4) | Yes | | | |
| t1 | integer | Acknowledge timeout t1 (sec) | No | 15 | | |
| t2 | integer | Connection ACKRSN clock t2 (sec) | No | 10 | | |
| t3 | integer | Connection TESTFR clock t3 (sec) | No | 20 | | |
| originator | integer | Provides a means for a controlling station to explicitly identify itself | No | 0 | 0 | 255 |

IEC 60870-5-104 Master parameters for *Signals*

| Parameter | Type | Description | Required | Default value (when not specified) | Range | |
|-----------------------|---------|---|--------------|---------------------------------------|-------|-----|
| | | | | | Min | Max |
| signal_name | string | User-friendly signal name | Yes | | | |
| device_alias | string | Alphanumeric string to identify a device | Yes | | | |
| signal_alias | string | Unique alphanumeric name of the signal to be Yes used | Yes | | | |
| source_device_alias | string | device_alias of a source device | For commands | | | |
| source_signal_aliases | string | signal_alias of a source signal | For commands | | | |
| enable | boolean | Enabling/disabling of an individual signal | No | 1 | 0 | 1 |
| log | integer | Allow signal to be logged. If log is 0 signal will not be logged. If log is more than 0 signal will be logged | No | 0 | | |
| gi | boolean | Including/excluding (1 or 0) signal from General Interrogation | No | 0 | 0 | 1 |
| common_address | integer | Address of a destination device | Yes | | | |
| function | integer | Function number | No | 0 | | |
| info_address | integer | Information object address | Yes | | | |

| | | | | | | |
|-----------|---------|--|----|---|--|--|
| data_type | integer | ASDU type identifier | No | | | |
| select_ms | integer | Time limit in milliseconds for command execution. Command select has to be performed before execution if this parameter is specified. Direct command execution can be performed only if this field is left empty or set to zero. | No | 0 | | |

Debugging an IEC 60870-5-104 Master application

If the configuration for IEC 60870-5-104 devices is set up, the handler for the protocol will start automatically. If a configuration is missing or contains errors, the protocol will not start. It is done intentionally to decrease unnecessary memory usage.

If IEC 60870-5-104 does not work properly (e.g. no communication between devices, data is corrupted, etc.), a user can launch a debug session from the command-line interface and find out why the link is not functioning properly or use WCC Utility to do that.

To launch a debugging session, a user should stop the *iec104-master* process and run the *iec104-master* command with respective flags.

- Step 1: Service must be stopped by entering the following command into the wccite:
/etc/init.d/iec104-master stop
- Step 2: After service is stopped it must be started with the preferred configuration file (JSON files found in /etc/ folder) and a debug level 7: **iec104-master -c /etc/iec104-master/iec104-master.json -d7**
- Step 3: Once the problem is diagnosed normal operations can be resumed with the following command:
/etc/init.d/iec104-master start

IEC 60870-5-104 command-line debugging options

```
-h [ -help ] Display help information
-V [ -version ] Show version
-d<debug level> Set debugging level
-c [ -config ] Config path
-r [ -raw ] Show raw telegram data
-f [ -frame ] Show frame data
-e [ -redis ] Show redis message
-R [ -readyfile ] Ready notification file
```


14.6 IEC 60870-5-104 Slave

IEC 60870-5-104 Slave is designed not to lose data acquired from Master protocols. The data that arrives from Master protocols is stored in the cache. This data is checked every second to manage further data sending. The data that leaves IEC 60870-5-104 Slave has output caches. They're built to provide switching between multiple sessions (redundant SCADA). If a new connection arrives, the old one is dropped, but data, that is stored in a cache, not sent and not confirmed by SCADA is transferred to the new connection.

Configuring IEC 104 Slave datapoints

To use IEC 60870-5-104 Slave in WCC Lite, it has to be configured via an Excel configuration. This configuration contains two Excel sheets where parameters have to be filled in Devices and Signals.

IEC 60870-5-104 Slave parameters for *Devices* tab

| Parameter | Type | Description | Required | Default value (when not specified) | Range | |
|--------------|---------|---|----------|---------------------------------------|-----------------------|-------|
| | | | | | Min | Max |
| name | string | User-friendly name for a device | Yes | | | |
| description | string | Description of a device | No | | | |
| device_alias | string | Alphanumeric string to identify a device | Yes | | | |
| enable | boolean | Enabling/disabling of a device | No | 1 | 0 | 1 |
| protocol | string | Protocol to be used | Yes | | IEC 60870-5-104 slave | |
| asdu_size | integer | Common address size in bytes | No | 2 | 1 | 2 |
| time_sync | boolean | Enable/disable (1 or 0) time synchronization | Yes | | | |
| port | integer | TCP port | No | 2404 | 0 | 65535 |
| ioa_size | integer | Information object address (IOA) size in bytes | No | 3 | 1 | 3 |
| swt | integer | Send window (SWT) | No | 12 | | |
| rwt | integer | Receive window (RWT) | No | 8 | | |
| cot_size | integer | Cause of transmission (COT) size in bytes | No | 2 | 1 | 2 |
| host | string | Space-separated remote host IP addresses (ipv4) | Yes | | | |
| bind_address | string | Bind to local IP address (ipv4) | No | 0.0.0.0 | | |
| t1 | integer | Acknowledge timeout t1 (sec) | No | 15 | 1 | 255 |
| t2 | integer | Connection ACKRSN clock t2 (sec), t2 should be less than t1 | No | 10 | 1 | 254 |

| | | | | | | |
|-----------------------|---------|--|---------------|-------|---|--------|
| t3 | integer | Connection TESTFR clock t3 (sec) | No | 20 | 1 | 172800 |
| message_size | boolean | The maximum length of a message | Yes | | 0 | 255 |
| cache_size | integer | Amount of data to be cached | Yes | | 0 | 1000 |
| tls | boolean | Enable/disable the use of TLS | No | 0 | 0 | 1 |
| tls_local_certificate | string | Local certificate for TLS connection | Yes (for TLS) | | | |
| tls_peer_certificate | string | Certificate authority file for TLS connection | No | | | |
| tls_private_key | string | A file consisting of the private key for TLS connection | No | | | |
| command_timeout_ms | integer | Time to execute a command before responding negatively. | No | 30000 | 0 | |
| command_age_ms | integer | The amount of time shift allowed for the command to still be executed. | No | 0 | 0 | |

IEC 60870-5-104 Slave parameters for *Signals* tab

| Parameter | Type | Description | Required | Default value (when not specified) | Range | |
|-----------------------|---------|---|--------------|---------------------------------------|-------|-----|
| | | | | | Min | Max |
| signal_name | string | User-friendly signal name | Yes | | | |
| device_alias | string | Alphanumeric string to identify a device | Yes | | | |
| signal_alias | string | Unique alphanumeric name of the signal to be Yes used | Yes | | | |
| source_device_alias | string | device_alias of a source device | For commands | | | |
| source_signal_aliases | string | signal_alias of a source signal | For commands | | | |
| enable | boolean | Enabling/disabling of an individual signal | No | 1 | 0 | 1 |
| log | integer | Allow signal to be logged. If log is 0 signal will not be logged. If log is more than 0 signal will be logged | No | 0 | 0 | 1 |
| gi | boolean | Including/excluding (1 or 0) signal from General Interrogation | No | 0 | 0 | 1 |
| common_address | integer | Address of a destination device | Yes | | | |
| info_address | integer | Information object address | Yes | | | |
| data_type | integer | ASDU type id. | Yes | | | |

| | | | | | | |
|-----------|---------|--|----|---|--|--|
| select_ms | integer | Time limit in milliseconds for command execution. Command select has to be performed before execution if this parameter is specified. Direct command execution can be performed only if this field is left empty or set to zero. | No | 0 | | |
|-----------|---------|--|----|---|--|--|

Debugging an IEC 60870-5-104 Slave application

If the configuration for IEC 60870-5-104 devices is set up, the handler for the protocol will start automatically. If a configuration is missing or contains errors, the protocol will not start. It is done intentionally to decrease unnecessary memory usage.

If IEC 60870-5-104 does not work properly (e.g. no communication between devices, data is corrupted, etc.), a user can launch a debug session from the command-line interface and find out why the link is not functioning properly or use WCC Utility to do that.

To launch a debugging session, a user should stop the *iec104-slave* process and run the *iec104-slave* command with respective flags.

- Step 1: Service must be stopped by entering the following command into the wccite:
/etc/init.d/iec104-slave stop
- Step 2: After service is stopped it must be started with the preferred configuration file (JSON files found in /etc/ folder) and a debug level 7: **iec104-slave-c /etc/iec104-slave/0_0_0_0_502.json -d7;** (0_0_0_0 - bind_address, 502 - port)
- Step 3: Once the problem is diagnosed normal operations can be resumed with the following command:
/etc/init.d/iec107-slave start

IEC 60870-5-10 command-line debugging options

```
-h [ -help ] Display help information
-V [ -version ] Show version
-d<debug level> Set debugging level
-c [ -config ] Config path
-r [ -raw ] Show raw telegram data
-f [ -frame ] Show frame data
-e [ -redis ] Show redis message
-R [ -readyfile ] Ready notification file
```