

Logout



To log out of the device graphical user interface a logout button in interface's upper right corner should be pressed. A user is automatically disconnected after ten minutes of inactivity. This ensures that the device would not be suspect to any deliberate damage made by unauthorized access.

🕒Revision #4

★Created 1 October 2020 14:15:21 by Raimundas Slavinskas

✎Updated 6 October 2020 13:34:37