

## 8.2 Site layout

PROTOCOL HUB	STATUS	SYSTEM	SERVICES	NETWORK	USERS	LOGOUT (ROOT)	 WCC LITE
--------------	--------	--------	----------	---------	-------	---------------	--

It provides the main navigation through the website. Contains the following sections:

- *PROTOCOL HUB*: configuration related to data exchange between WCC Lite and other devices.
- *STATUS*: system information and diagnostics.
- *SYSTEM*: basic system settings such as time setup.
- *SERVICES*: various other services.
- *NETWORK*: network-related settings and services.
- *USERS*: existing user groups and management of their permissions
- *LOGOUT*: user logout.

🕒Revision #1

★Created 22 November 2024 07:15:21 by Gabriele

✎Updated 22 November 2024 07:24:23 by Gabriele