

## 5.4 Dual-SIM card slot

WCC Lite has an optional Dual-SIM card modem. To access both SIM cards, remove a transparent front panel cover and press through the marked hole with a small tool until the SIM holder pops out.



Figure 6: WCC Lite Dual-SIM card holder

To insert SIM cards, remove the Dual-SIM holder and fit SIM cards into it. Insert holder with SIM cards into the slot.

**Note:** Be careful when removing or inserting DUAL-SIM holder, as SIM cards can fall out.

**Note:** WCC Lite will automatically detect a SIM card insertion or removal.

Revision #2

★ Created 7 October 2022 10:35:48 by Lukas Taroza

✎ Updated 23 November 2022 09:31:34 by Gabriele