

5.4 Dual-SIM card slot

WCC Lite has an optional Dual-SIM card modem. To access both SIM cards, remove a transparent front panel cover and press through the marked hole with a small tool until the SIM holder pops out.



Figure 6: WCC Lite Dual-SIM card holder

To insert SIM cards, remove the Dual-SIM holder and fit SIM cards into it. Insert holder with SIM cards into the slot.

Note: Be careful when removing or inserting DUAL-SIM holder, as SIM cards can fall out.

Note: WCC Lite will automatically detect a SIM card insertion or removal.

Revision #1

★Created 11 January 2024 09:21:54 by Gabriele

✎Updated 11 January 2024 09:38:18 by Gabriele