

26.1 Introduction

SMS receiver is a service responsible for command execution that was received via text message. The service is available on WCC Lite with the modem. To use this service a working SIM card is also required. This chapter will describe command types and configuration for WCC Lite as well as an example of the said configuration.

🕒Revision #2

★Created 26 January 2024 13:13:15 by Gabriele

✎Updated 17 June 2024 11:55:16 by Gabriele