

# 5.1 Mounting

To mount the device:

1. Secure the top of the mounting clip onto a DIN rail.
2. Push the bottom of a device forward to fix the clip in place.

To dismount the device:

1. Pull the red-coloured clip downwards (found at the bottom side of the DIN rail).
2. Pull back the bottom of the device.
3. Pull the device upwards to dismount it.




Figure 2: WCC Lite DIN rail mounting clip

---

🔄Revision #2

★Created 26 January 2024 13:13:14 by Gabriele

✎Updated 13 June 2024 08:39:44 by Gabriele