

## 5.4 Dual-SIM card slot

WCC Lite has an optional dual-SIM card modem. To access both SIM cards, remove a transparent front panel cover and press through the marked hole with a small tool until the SIM holder pops out.




Figure 6: WCC Lite Dual-SIM card holder

To insert SIM cards, remove the Dual-SIM holder and fit SIM cards into it. Insert the holder with SIM cards into the slot.

**Note:** Be careful when removing or inserting a DUAL-SIM holder, as SIM cards can fall out.

**Note:** WCC Lite will automatically detect a SIM card insertion or removal.

Revision #3

★Created 26 January 2024 13:13:14 by Gabriele

✎Updated 13 June 2024 08:41:07 by Gabriele