

8.2 Site layout



It provides the main navigation through the website. Contains the following sections:

- *PROTOCOL HUB*: configuration related to data exchange between WCC Lite and other devices.
- *STATUS*: system information and diagnostics.
- *SYSTEM*: basic system settings such as time setup.
- *SERVICES*: various other services.
- *NETWORK*: network-related settings and services.
- *USERS*: existing user groups and management of their permissions
- *LOGOUT*: user logout.

⊕Revision #2

★Created 26 January 2024 13:13:12 by Gabriele

✎Updated 13 June 2024 08:51:49 by Gabriele