

26.1 Introduction

SMS receiver is a service responsible for command execution that was received via text message. The service is available on WCC Lite with the modem. To use this service a working SIM card is also required. This chapter will describe command types and configuration for WCC Lite as well as an example of the said configuration.

🕒Revision #1

★Created 27 February 2025 08:00:45 by Gabriele

✎Updated 27 February 2025 08:08:33 by Gabriele