

26.1 Introduction

SMS receiver is a service responsible for command execution that was received via text message. The service is available on WCC Lite with the modem. To use this service a working SIM card is also required. This chapter will describe command types and configuration for WCC Lite as well as an example of the said configuration.

🕒Revision #1

★Created 22 November 2024 07:15:25 by Gabriele

✎Updated 22 November 2024 07:24:23 by Gabriele