

# 8.9 Logout



To log out of the device graphical user interface a logout button in the interface's upper right corner should be pressed. A user is automatically disconnected after ten minutes of inactivity. This ensures that the device would not be suspected of any deliberate damage made by unauthorized access.

---

🕒Revision #1  
★Created 27 February 2025 08:00:43 by Gabriele  
✎Updated 27 February 2025 08:08:34 by Gabriele