


# 8.2 Site Layout

## Site layout

|              |        |        |          |         |       |               |  |
|--------------|--------|--------|----------|---------|-------|---------------|--|
| PROTOCOL HUB | STATUS | SYSTEM | SERVICES | NETWORK | USERS | LOGOUT (ROOT) |  WCC LITE |
|--------------|--------|--------|----------|---------|-------|---------------|--|

It provides the main navigation through the website. Contains the following sections:

- *PROTOCOL HUB*: configuration related to data exchange between WCC Lite and other devices.
- *STATUS*: system information and diagnostics.
- *SYSTEM*: basic system settings such as time setup.
- *SERVICES*: various other services.
- *NETWORK*: network related settings and services.
- *USERS*: existing user groups and management of their permissions
- *LOGOUT*: user logout.

🔄Revision #1

★Created 26 November 2021 10:34:03

✎Updated 26 November 2021 10:37:28