

Excel configuration

How to use excel configuration. What are functions supported.

- Device configuration
- Signals sheet
- Uploading configuration
- Mathematical functions

Device configuration

Protocol HUB uses configuration in excel file format. Each sheet represents a specific part of configuration:


- Devices contains device list and protocol related configuration.
- Signals contains a list of signals and their options.

First line on each sheet is a header row that contains parameter name for each column. Header order determines parameter names for each following row. Every line after the header is a new entry. An empty row is interpreted as end of sheet. Any rows after empty row are discarded.

Devices sheet

Devices sheet contains all devices to be configured on gateway. Each row represents one device and its settings. Following options are required for each device:

- name - Name of the device. Used for representation only.
- description - A short description for the device. Used for representation only.
- device_alias - A unique short name for the device. It is used for linking signals to a device.

 Alias can only contain alphanumeric characters and dashes (- and _). Alias must be unique for each device.

- protocol - Protocol type to use on device. Exact values of protocols are written in every protocol documentation. Please look into range of supported protocols:

IEC 61850 MMS:

- IEC 61850 Client (since FW 1.5.0)
- IEC 61850 Server (since FW 1.5.0)

IEC 60870-5:

- IEC 60870-5-101 master
- IEC 60870-5-101 slave
- IEC 60870-5-103 master
- IEC 60870-5-104 master
- IEC 60870-5-104 slave

DNP 3.0 Serial/LAN/WAN:

- DNP3 Master
- DNP3 Slave

Modbus Serial/TCP:

- Modbus RTU/ASCII
- Modbus TCP

Metering protocols:

- DLMS/COSEM (since FW 1.3.0)
- IEC 62056-21 (since FW 1.2.13)
- MBus Serial
- MBus TCP
- Elgama (Meters based on IEC 62056-21 / 31 protocols)

Industrial IOT protocols:

- MQTT

- RESTful API

Specific protocols:

- Aurora (ABB PV inverters protocol)
- PowerOne (ABB PV inverters protocol)
- SMA Net (SMA PV inverters protocol)
- Kaco (Kaco PV inverters protocol)
- Ginlong (Ginlong PV inverters protocol)
- Solplus (Solutronic AG PV inverters protocol)
- ComLynx (Danfoss PV inverters protocol)
- Delta (Delta PV inverters protocol)
- Windlog (Wind sensors from RainWise Inc.)
- Vestas (Wind turbines protocol)
- Internal data
- VBus.



Although device name rules aren't strictly enforced, it is highly advised to give a unique name for every new device. Identical device names might introduce confusion while searching for signal in Imported Signals tab.

Optional settings

- enable - Flag to enable or disable device on system. Can contain values 0 or 1.
- event_history_size - Maximum number of signal events to save on device for later review. Older records will be erased. This feature is only available on cloud firmware.

Serial port settings

Required for any protocol that uses serial line communication.

- device - Serial port for communication (PORT1/PORT2)
- baudrate - Serial port speed. Valid values:

- 300
- 600
- 1200
- 2400
- 4800
- 9600
- 19200
- 38400
- 57600
- 115200

- databits - Number of data bits (6-9)
- stopbits - Number of stop bits (1-2)
- parity - Parity mode (none/even/odd)
- flowcontrol - Flow control method (none/hardware/software)

TCP/IP settings

Settings for any protocol that uses communication over TCP/IP. Note that all TLS certificates and keys are stored in single folder therefore only name and not the path should be filled in respective fields.



TLS fields are only supported for IEC 61850 Client and Server, IEC-60870-5-104 Slave and DNP3 Master and Slave, MQTT.

- ip - IP address for master protocol to connect to;
- bind_address - one of local IP addresses to bind the server to. Connections through other network devices will be ignored;
- host - space separated host IP addresses of master devices;
- port - TCP port to listen for incoming connections;
- tls_local_certificate - name of local TLS certificate;
- tls_peer_certificate - name of certificate authority (CA) TLS certificate;
- tls_private_key - name of private key for making TLS connections.

Signals sheet

Signals sheet contains all signals linked to devices. Each signal is defined in single row. Signal list can be split in multiple sheets. Each sheet name may start as Signals.

Required attributes

These attributes are mandatory for every configured signal. Every Excel configuration should have specified them in first row of Signals sheet:


- **signal_name** - Name of the signal. Used for representation only.
- **device_alias** - Alias of a device defined in Devices sheet. Signal is linked to a matching device.
- **signal_alias** - A unique short name for the signal. It is used for linking signal to other signals. Alias can only contain alphanumeric characters and dashes (- and _). Device and signal alias combination must be unique.

Optional attributes


Optional attributes are required depending on protocol in use and they can be used to extend protocol functionality:

- **source_device_alias** - Alias of a source device defined in Devices sheet. If a user intends to use several signals and combine them via mathematical or logical function, every alias should be separated by a newline symbol (in the same cell). An operation used must also be defined in an operation column.
- **source_signal_alias** - Alias of a source signal defined in Signals sheet. If a user intends to use several signals and combine them via mathematical or logical function, every alias should be separated by a newline symbol (in the same cell). An operation used must also be defined in an operation column. Every `source_signal_alias` should be posted in the same line as its respective `source_device_alias`. Aliases can only contain alphanumeric characters and dashes (- and _). Device and signal alias combination must be unique.
- **enable** - Flag to enable or disable signal on system. Can contain values 0 or 1.
- **tag_type** - Tag type. Simple signals are polled from device. Virtual signals are computed internally.
- **off_message** - Message to display when single point or double point signals are in OFF state.
- **on_message** - Message to display when single point or double point signals are in ON state.
- **units** - Signal value measurements units.
- **multiply** - Multiply value by this number.
- **add** - Add this number to a value.
- **sum_signals** - Define other signal values to add to current signal. This field uses following **format**: `dev_alias/tag_alias`. Multiple signals can be defines usign commas.
- **min_value** - Minimum expected value. If result is lower than this value, invalid flag is raised.
- **max_value** - Maximum expected value. If result is higher than this value, overflow flag is raised.
- **absolute_threshold** - Absolute threshold level.
- **integral_threshold** - Integral threshold level.
- **integral_threshold_interval** - Integral threshold addition interval in milliseconds.
- **threshold_units** - Units used in threshold level fields (percent/real).
- **log_size** - Maximum number of records for this tag to keep in storage for CloudIndustries logging.
- **suppression_values** - Space separated numeric values to be used in suppression.
- **suppression_time_ms** - Suppression time in milliseconds.
- **operation** - Mathematical or logical operation to be used for signals defined in `source_signal_alias` column. Following mathematical operations for source signal values can be used: avg (average of all values), min (lowest value), max (highest value), median (median value) and sum (all values accumulated to a single number). Logical operations, intended for unsigned integers only, are or and and operations.
- **bit_select** - selecting an individual bit of an integer number; bit numeration starts from zero.
- **math_expression** - a mathematical expression for signal value to be evaluated against. Explained in detail in **Mathematical expressions document**.

Picture. Result of using an absolute threshold:



Picture. Result of using an integral threshold:



Signal recalculation operation priority

A value generated by some protocol usually has to be recalculated in one way or another. This might mean changing the value of an argument as well as adding flags needed for other protocols to correctly interpret results. As recalculation is a sequential process, some actions are done before others. The sequence of operations done to a value is as follows:

- *Edition of attributes* Attributes for further interpretation are added. This might, for example, include flag to show that a signal resembles an answer to a command;
- *Mathematical calculations*. **multiply**, **add**, **bit_select** and **math_expression** columns are evaluated here;
- *Usage of last value*. Decision if last value for a signal should be used if a new value of a signal is not a number (NaN) or contains a non-topical (NT) flag;
- *Limiting of values*. If a value exceeds a lower or higher configured limit, value is approximated not be lower (or higher) than the limit. An additional invalid (IV) or overflow (OV) flag is added as frequently used in IEC-60870-5 protocols;
- *Suppression of values* As electrical circuits can be noisy, protocols may generate multiple values in a short amount of time. What is more, some values are considered as intermediary and ideally should not be sent to SCADA unless they stay in the same state for some amount of time. `suppression_values` and `suppression_time_ms` are used to configure this functionality;
- *Threshold checking*. If a new signal doesn't cross a threshold target value, value is suppressed and not used in further stages. `absolute_threshold`, `integral_threshold`, `integral_threshold_interval`, `threshold_units` columns are used to configure this functionality.

Not all of the elements in this sequence have to be configured, missing operations are skipped and values are fed to a further stage of signal recalculation.

number_type field

This field is required for some protocols to determine a method to retrieve a signal value from hexadecimal form. Available values:

- **FLOAT** - 32-bit single precision floating point value according to IEEE 754 standard
- **DOUBLE** - 64-bit double precision floating point value according to IEEE 754 standard
- **DIGITAL** - 1-bit boolean value
- **UNSIGNED8** - 8-bit unsigned integer (0 - 255)

- **SIGNED8** - 8-bit signed integer (-128 - 127)
- **UNSIGNED16** - 16-bit unsigned integer (0 - 65535)
- **SIGNED16** - 16-bit signed integer (-32768 - 32767)
- **UNSIGNED32** - 32-bit unsigned integer (0 - 4294967295)
- **SIGNED32** - 32-bit signed integer (-2147483648 - 2147483647)
- **UNSIGNED64** - 64-bit unsigned integer (0 - 18446744073709551615)
- **SIGNED64** - 64-bit signed integer (-9223372036854775808 - 9223372036854775807)

Number conversion uses **big endian** byte order by default. Converted data will be invalid if byte order on connected device side is different. In such case byte swap operations can be used. Adding swap prefixes to number type will set different a byte order while converting values. Following swap operations are available:

- **SW8** - Swap every pair of bytes (8 bits) (e.g., **0xAABBCCDD** is translated to **0xBBAAADDCC**);
- **SW16** - Swap every pair of words (16 bits) (e.g., **0xAABBCCDD** is translated to **0xCCDDAABB**);
- **SW32** - Swap every pair of two words (32 bits) (e.g., **0x1122334455667788** is translated to **0x5566778811223344**);

Table. Example of using different swapping functions:

Address	0	1	2	3	4	5	6	7
Original number	Byte 0	Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6	Byte 7
SW8	Byte 1	Byte 0	Byte 3	Byte 2	Byte 5	Byte 4	Byte 7	Byte 6
SW16	Byte 4	Byte 5	Byte 6	Byte 7	Byte 1	Byte 6	Byte 4	Byte 5
SW32	Byte 4	Byte 5	Byte 6	Byte 7	Byte 0	Byte 1	Byte 2	Byte 3
SW8.SW16	Byte 3	Byte 2	Byte 1	Byte 0	Byte 7	Byte 6	Byte 5	Byte 4
SW8.SW32	Byte 4	Byte 4	Byte 7	Byte 6	Byte 1	Byte 0	Byte 3	Byte 2
SW8.SW16.SW32	Byte 7	Byte 6	Byte 5	Byte 4	Byte 3	Byte 2	Byte 1	Byte 0

Where Byte x, means bit x position in byte.

Add a dot separated prefix to number format to use byte swapping. Multiple swap operations can be used simultaneously. For example, use `SW8.SW16.SIGNED32` to correctly parse a 32-bit signed integer in a little endian format. Table 35 shows in detail how bytes, words or double words can be swapped and how swapping functions can be combined to make different swapping patterns. Table shows how byte swap is done for 64-bit (8-byte) numbers. It doesn't matter if it is an unsigned/signed integer or double, byte swapping is considered a bit-level operation. If a number is shorter than 64 bits, the same logic applies, the only difference is unavailability of some swapping operations (`SW32` for 32-bit and smaller numbers). Using such unavailable operation might lead to an undefined behaviour.

Linking signals

Signals can be linked together to achieve data transfer between several protocols. If a signal source is defined, all output from that source will be routed to the input of target signal. This way events polled from a modbus device (e.g., Modbus, IEC 60870-5, etc.) can be delivered to external station over a different protocol. A signal source is required if a signal is created on a slave protocol configuration to link events between protocols.

Example 1:


To read a coil state from a Modbus device and transfer it to IEC 60870-5-104 station, following steps may be taken:

1. Create a Modbus master configuration in Devices sheet.
2. Create a IEC 60870-5-104 slave configuration in Devices sheet.
3. Create a signal on master device to read coil status (function 1).
4. Create a signal on slave device with single point type (data_type = 1).
5. Set source_device_alias and source_signal_alias fields on slave device signal to match device_alias and signal_alias on master device's coil signal.

Example 2

To write a coil state to a Modbus device on a command from IEC 60870-5-104 station, following steps may be taken:


1. Follow steps 1-3 from example 1.
2. Create a signal on slave device with single command type (data_type = 45).
3. Set source_device_alias and source_signal_alias fields on master configuration coil signal to match device_alias and signal_alias on slave device's command signal. Coil will be written to a value received by a command.
4. Set source_device_alias and source_signal_alias fields on command signal to match device_alias and signal_alias on master device's coil signal. A command termination signal will be reported to the station on coil write result.

 For additional information regarding the configuration of IEC 60870-5-101/103/104 protocols, please refer to "IEC 60780-5-101/103/104 PID interoperability for WCC Lite devices", accordingly.

Uploading configuration

As of WCC Lite version v1.4.0 there are three separate ways to import the configuration: import an Excel file via web interface, generate compressed configuration files and later upload them via web interface; or generate compressed configuration files and upload them via utility application.


For WCC Lite versions v1.4.0, name of the file is shown in Protocol Hub->Configuration. Older versions only allow configuration file to be stored to a file called phub.xlsx and later downloaded with a custom-built name reflecting date of a download. Upgrade process from older version to versions v1.4.0 and above when preserving configuration files automatically makes the necessary changes to enable this new functionality of WCC Lite.

 If a user intends to downgrade firmware to versions older than version v1.4.0 from newer versions, he/she must first download the configuration files and later reupload the configuration after finishing the upgrade process.

Importing an Excel file

Excel file can be imported without any external tools. This option can be used where there is no internet connection or only minor change has to be applied. This way of importing is not suitable for validation of Excel configuration file.

 **Generating configuration is a resource-intensive task.** It might take up to 10 minutes depending on configuration complexity

 Supported types of an Excel configuration: .xlsx, .xlsm, .xltm, .xltx

To upload an Excel file, open [Protocol Hub->Configuration](#) screen in Web interface, select Configuration file and press Import configuration.

Generating .zip file

To accelerate a task of generating configuration a computer can be used. For this user should download WCC Excel Utility application. Upon opening an application, user should search for a field called Excel file which lets to choose an Excel file for which a conversion should be made. Output file should be filled out automatically, however, this value can be edited.


To make a conversion press Convert. If there are no errors found in the configuration, output file should contain the generated configuration, otherwise, error message is shown to a user.

This .zip file can be uploaded via Web interface, using the same tools as used for import of an Excel file.

Uploading configuration remotely

As of WCC Lite version v1.4.0 generated configuration files can be uploaded by a click of button. There are four parameters (not counting the configuration file itself) that have to be filled in before starting upload:

- Hostname: an IP address for device to connect to. This field conforms to hostname rules, therefore, if invalid value is selected, it is reset to default (192.168.1.1);
- Port: a PORT number to which a SSH connection can be made; valid values fall into a range between 1 and 65535; if invalid value is selected, it is reset to default (22);
- Username: a username which is used to make a SSH connection; make sure this user has enough rights, preferably root;
- Password: a password of a user used for establishing a SSH connection;

 Configuration can only be uploaded if a port used for SSH connection is open for IP address filled in hostname entry field. Please check WCC Lite firewall settings in case of connection failure.

To upload a configuration remotely, press Upload configuration. If no errors occur, you should finally be met with text output mentioning configuration has been applied. During the course of upload process the aforementioned button is disabled to prevent spanning multiple concurrent processes.

Mathematical functions

Signal value might require some recalculation or signal update prior to being sent. Understandably, existing columns in Excel configuration like `multiply`, `add`, `bit_select` might not be flexible enough. To overcome these limitations, symbolic mathematical expressions can be configured to do calculations automatically on every update of a signal.


Feature list:

- Optimized for speed
 - High parsing performance
 - if-then-else operator with lazy evaluation
- Default implementation with many features
 - 25 predefined functions
 - 18 predefined operators
- Unit support
 - Use postfix operators as unit multipliers (3m -> 0.003)

Mathematical functions

Table. Supported mathematical functions:

Name	Argument count	Explanation
sin	1	sine function (rad)
cos	1	cosine function (rad)
tan	1	tangent function (rad)
asin	1	arcus sine function (rad)
acos	1	arcus cosine function (rad)
atan	1	arcus tangent function (rad)
sinh	1	hyperbolic sine function
cosh	1	hyperbolic cosine
tanh	1	hyperbolic tangent function
asinh	1	hyperbolic arcus sine function
acosh	1	hyperbolic arcus tangent function
atanh	1	hyperbolic arcus tangent function
log2	1	logarithm to the base 2
log10	1	logarithm to the base 10
log	1	logarithm to base e (2.71828...)
ln	1	logarithm to base e (2.71828...)
exp	1	e raised to the power of x
sqrt	1	square root of a value
sign	1	sign function -1 if x<0; 1 if x>0
rint	1	round to nearest integer
abs	1	absolute value
min	variable	min of all arguments
max	variable	max of all arguments
sum	variable	sum of all arguments
avg	variable	mean value of all arguments
floor	1	round down to the nearest integer
mod	variable	modulo operation

 It should be noted that trigonometric functions (excluding hyperbolic functions) only support arguments in radians. This means that arguments for this function have to be recalculated if angle is defined in degrees.



Value recalculation is only triggered on signal change of the preconfigured signal. That means that using other signals (via TagValue() call) does not trigger value update.



Some mathematical expression cannot be mathematically evaluated in some conditions, for example, square root cannot be found for negative numbers. As complex numbers are not supported, result is then equal to Not a Number (NaN). These results are marked with an invalid (IV) flag.

Binary operations

Table. Supported binary operators:

Operator	Description	Priority
=	assignment	-1
»	right shift	0
«	left shift	0
&	bitwise and	0
	bitwise or	0
&&	logical and	1
	logical or	2
<=	less or equal	4
>=	greater or equal	4
!=	not equal	4
==	equal	4
>	greater than	4
<	less than	4
+	addition	5
-	subtraction	5
*	multiplication	6
/	division	6
^	raise x to the power of y	7

Ternary operators can be used. This expression can be compared to the operator supported by C/C++ language (Table 39). Condition is written before a question (?) sign. If condition is true, result after question sign is selected. If condition is false, result after colon (:) is selected.

Ternary operations

Table. Supported ternary operators

Operator	Description	Remarks
?:	if then else operator	C++ style syntax

Examples

Users can construct their own equation by using the aforementioned operators and functions. These examples can be seen in Table below.

Table. Example expressions

Expression	Description
value * 0.0001	Multiply the tag by a constant.
value + TagValue("tag/dev_alias/sig_alias/out")	Add value of tag/dev_alias/sig_alias/out to the current tag.
sin(value)	Return a predefined sine function value of the tag.
(value>5)? 1: 0	If the value is greater than 5, the result should be equal to 1, otherwise - equal to 0

Variable called "value" is generated or updated on every signal change and represents the signals being configured. If another value from tag list is intended to be used, one should use `TagValue()` function to retrieve its last value.

The inner argument of `TagValue()` function has to be described in a Redis topic structure of WCC Lite. That means that it has to be constructed in a certain way. Quotes should be used to feed the topic name value, otherwise expression evaluation will fail.

Every Redis topic name is constructed as `tag/[device_alias]/[signal_alias]/[direction]`. Prefix `tag/` is always used before the rest of argument. `device_alias` and `signal_alias` represent columns in Excel configuration. Direction can have one of four possible values - `out`, `in`, `rin`; all of which depend on the direction data is sent or acquired device-wise. For example, "out" keyword marks data sent out of WCC Lite device, whereas "in" direction represents data that WCC Lite is waiting to receive, for example, commands. Additional "r" before either direction means that data is raw, it is presented the way it was read by an individual protocol.

Signal mathematics


In this section you will be shown how "math_expression" and other mathematical functions can be used in case of common signals. You can download configuration to follow along [here](#). Signals which we are concerned with in this section are highlighted in green color.

Let us analyze what mathematical functions are configured for the signals. For both second and third signals the same expression will be used: "**value + TagValue("tag/Master/RHR0/out")**". The only difference is that for the second signal scale function "add" was used.

signal_name	device_alias	signal_alias	source_device_alias	source_signal_alias	enable	job_todo	tag_job_todo	number_type	multiply	add	bit_select	source_math_expression	math_expression
Read Holding Register 0	Master	RHR0			1	3;0;36	3;0;1	SIGNED16					
Write Single Register 1	Master	WSR1	Master	RHR0	1	6;0;36	6;1;1	SIGNED16					
Read Holding Register 2	Master	RHR2			1	3;0;36	3;2;1	SIGNED16		5			value + TagValue("tag/Master/RHR0/out")
Write Single Register 3	Master	WSR3	Master	RHR2	1	6;0;36	6;3;1	SIGNED16					
Read Holding Register 4	Master	RHR4			1	3;0;36	3;4;1	UNSIGNED16					value + TagValue("tag/Master/RHR0/out")

In this signal configuration the value of second signal is calculated by adding the current value of the second signal with the value of the first signal. Then the sum of two signals is going to be increased by 5. The third signal is going to be calculated in the same way except that 5 is not going to be added.

To see how it works let us start Modbus TCP Slave simulation in Vinci application. You can download the simulation [here](#).



Protocol: Modbus TCP

Mode: Slave (Server)

STOP

IP: 192.168.1.2

Port: 502

Settings
Console
Statistic

Slave	Function	Address	Value	FormattedValue	Name
1	3	0	1	1	Register0
1	3	1	1		
1	3	2	2	2	Register2
1	3	3	8		
1	3	4	3	3	Register4

In the picture above you can see 6 registers. However our main focus is null, second and forth registers (Register0, Register2, Register4) since the first three signals of Modbus Master protocol (RHR0, RHR2 and RHR4) are reading the values of those registers (accordingly).

Let us go to WCC Lite web-interface to see how these signals are displayed there:

IMPORTED SIGNALS

Device	Signal	Value	Units	State	Attributes	Time
Master Protocol	Read Holding Register 0	1				2023-07-26 12:07:09.35
Master Protocol	Write Single Register 1	1			cot=10	2023-07-26 12:07:10.73
Master Protocol	Read Holding Register 2	8				2023-07-26 12:07:09.58
Master Protocol	Write Single Register 3	8			cot=10	2023-07-26 12:07:10.74
Master Protocol	Read Holding Register 4	4				2023-07-26 12:07:10.21

As we can see the values of third and fifth signals have been modified ($RHR2 = 2+1+5 = 8$; $RHR3 = 3+1 = 4$). However the values of the signals that are displayed in the web-interface are intermediate so to speak. All the math is done in the protocol services (Modbus TCP Master in this case). Then those values are transmitted to REDIS service. The values that are displayed in the web-interface are REDIS values. We are going to see why it is important in another example.

Now it was mentioned that the values of third and fifth signals depend on the value of the first one. Let us see what will happen if we change the value of the Register 0. To do so we need to return to VINCI application. Locate Register 0 and double click on it. A menu with the register parameters will appear.

[illegible]

Now let us change the value of the register to 2:

Tag

Name: Register0

Type: Read Holding Registers (3)

Slave: 1 Address: 0

Format: Signed

Value: 2

Now it would be expected that the value of second and third signals would become 9 and 5 accordingly (RHR2 = 2+2+5 = 9; RHR3 = 3+2 = 5). However if one would check WCC Lite web-interface right after that, one could notice that second and third signals remained unchanged:

PROTOCOL HUB

STATUS

SYSTEM

SERVICES

NETWORK

USERS

LOGOUT (ROOT)

CONFIGURATION

IMPORTED SIGNALS

EVENT LOG

PROTOCOL CONNECTIONS

SCRIPT-RUNNER

IMPORTED SIGNALS

Device	Signal	Value	Units	State	Attributes	Time
Master Protocol	Read Holding Register 0	2				2023-07-26 12:59:26.77
Master Protocol	Write Single Register 1	2			cot=10	2023-07-26 12:59:26.86
Master Protocol	Read Holding Register 2	8				2023-07-26 12:48:42.64
Master Protocol	Write Single Register 3	8			cot=10	2023-07-26 12:48:42.91
Master Protocol	Read Holding Register 4	4				2023-07-26 12:48:42.64
Master Protocol	Write Single Register 5	4			cot=10	2023-07-26 12:48:42.94

To explain this let us look again at the math expression of these signals. The equation **value + TagValue("tag/Master/RHR0/out")** consists of two operands "value" and "TagValue("tag/Master/RHR0/out")". Currently the system is designed in such a way that only if "value" operand has changed, only then there is going to be a change in a signal's value. So that if values of second and forth registers are changed (increased by one in this example) then the values of third and fifth signals are going to change taking into account the previous change in value of Register 0 (RHR2 = 2+3+5 = 10; RHR3 = 2+4 = 6).

Protocol: Modbus TCP

Mode: Slave (Server)

STOP

IP: 192.168.1.2

Port: 502

Settings

Console

Statistic

Slave	Function	Address	Value	FormattedValue	Name
1	3	0	2	2	Register0
1	3	1	2		
1	3	2	3	3	Register2
1	3	3	10		
1	3	4	4	4	Register4
1	3	5	6		

PROTOCOL HUB

STATUS

SYSTEM

SERVICES

NETWORK

USERS

LOGOUT (ROOT)

CONFIGURATION

IMPORTED SIGNALS

EVENT LOG

PROTOCOL CONNECTIONS

SCRIPT-RUNNER

IMPORTED SIGNALS

Device	Signal	Value	Units	State	Attributes	Time
Master Protocol	Read Holding Register 0	2				2023-07-26 12:59:26.77
Master Protocol	Write Single Register 1	2			cot=10	2023-07-26 12:59:26.86
Master Protocol	Read Holding Register 2	10				2023-07-26 13:30:23.64
Master Protocol	Write Single Register 3	10			cot=10	2023-07-26 13:30:23.73
Master Protocol	Read Holding Register 4	6				2023-07-26 13:30:28.68
Master Protocol	Write Single Register 5	6			cot=10	2023-07-26 13:30:28.77

Command mathematics

In this section you will be shown how "math_expression", and other mathematical functions can be used in case of command signals. You can download configuration to follow along [here](#). Signals which we are concerned with in this section are highlighted in blue color.

Let us analyze what mathematical functions are configured for the signals.

signal_name	device_alias	signal_alias	source_device_alias	source_signal_alias	enable	job_todo	tag_job_todo	number_type	multiply	add	bit_select	source_math_expression	math_expression
Read Holding Register 0	Master	RHR0			1	3;0;36	3;0;1	SIGNED16	2				
Write Single Register 1	Master	WSR1	Master	RHR0	1	6;0;36	6;1;1	SIGNED16					
Read Holding Register 2	Master	RHR2			1	3;0;36	3;2;1	SIGNED16					
Write Single Register 3	Master	WSR3	Master	RHR2	1	6;0;36	6;3;1	SIGNED16	2				
Read Holding Register 4	Master	RHR4			1	3;0;36	3;4;1	SIGNED16					
Write Single Register 5	Master	WSR5	Master	RHR4	1	6;0;36	6;5;1	SIGNED16				value - TagValue("tag/Master/RHR0/out")	value + TagValue("tag/Master/RHR0/out")
Read Holding Register 6	Master	RHR6			1	3;0;36	3;6;1	SIGNED16					
Write Single Register 7	Master	WSR7	Master	RHR6	1	6;0;36	6;7;1	SIGNED16			3		

First four signals are going to be used for scale function analysis. To see how it works let us start Modbus TCP Slave simulation in Vinci application. You can download the simulation [here](#).

Protocol: Modbus TCP

Mode: Slave (Server)

STOP

IP: 192.168.1.2

Port: 502

Settings

Console

Statistic

Slave	Function	Address	Value	FormattedValue	Name
1	3	0	4	4	Register0
1	3	1	8		
1	3	2	4	4	Register2
1	3	3	2		

Let us go to WCC Lite web-interface to see how these signals are displayed there:

PROTOCOL HUB

STATUS

SYSTEM

SERVICES

NETWORK

USERS

LOGOUT (ROOT)

WCC LITE

CONFIGURATION

IMPORTED SIGNALS

EVENT LOG

PROTOCOL CONNECTIONS

SCRIPT-RUNNER

IMPORTED SIGNALS

Device	Signal	Value	Units	State	Attributes	Time
<div></div>	<div></div>	<div></div>	<div></div>	<div></div>	<div></div>	<div></div>
Master Protocol	Read Holding Register 0	8				2023-07-26 15:03:53.17
Master Protocol	Write Single Register 1	8			cot=10	2023-07-26 15:03:53.37
Master Protocol	Read Holding Register 2	4				2023-07-26 15:03:53.17
Master Protocol	Write Single Register 3	4			cot=10	2023-07-26 15:03:53.40

As one can notice the values displayed in Vinci application differ from values displayed in web-interface. To better understand the results let us see step by step how signals are modified.

The first signal RHR0 reads the value of Register 0 which is equal to 4. After read operation the value is multiplied by two in the master protocol service. Then signal is transmitted to REDIS service. REDIS value is presented in web-interface. Then the same value 8 is written to Register 1 by sending WSR1 command signal. Finally the value of WSR1 signal is displayed in Vinci simulation.

The third signal RHR2 behaves quite the same as the first RHR0 signal. It reads value of Register 2 and without performing any scaling operations transmits value to REDIS. It again can be seen in the web-interface. While still in REDIS service the value of Register 2 is passed to WSR3 signal. Then command signal WSR3 is transmitted back to Modbus Master protocol service where the value of the signal is scaled. One could expect that the value of the signal would be multiplied by two but it is divided by two. Then the value of 2 is displayed in Vinci Slave simulation. After changing the value of Register 3 WSR3 signal is sent back from Master Protocol service to REDIS. On its way the signal again passes signal scaling place where it is again multiplied by two. This is why we see in the web-interface that the value of forth signal WSR3 is 4.

All the moments when a signal passes a place where its value is scaled can be seen by turning on a debugger session. To do so one should connect to WCC Lite via Ubuntu terminal in Terminal application. Then Modbus Master protocol needs to be stopped by sending `"/etc/init.d/modbus-master stop"`. Then Modbus Master protocol needs to be started again with -m flag (m for math) `"modbus-master -d7 -m -c /etc/modbus-master/modbus-tcp.json"`.

```
root@wcc-lite:~# /etc/init.d/modbus-master stop
root@wcc-lite:~# modbus-master -d7 -m -c /etc/modbus-master/modbus-tcp.json
```


If you scroll up after starting the session you will be able to find how both RHR0 and WSR3 signals are scaled after passing signal scaling place.

```
[DEBUG] SERVICE_MATH: Signal: tag/Master/RHR0/rout
[DEBUG] SERVICE_MATH: Value: 4
[DEBUG] SERVICE_MATH: value * 2 = 8

[DEBUG] SERVICE_MATH: Signal: tag/Master/WSR3/rin
[DEBUG] SERVICE_MATH: Value: 4
[DEBUG] SERVICE_MATH: (value) / 2 = 2
[DEBUG] SERVICE_MATH: Signal: tag/Master/WSR3/rout
[DEBUG] SERVICE_MATH: Value: 2
[DEBUG] SERVICE_MATH: value * 2 = 4
```


Why is it the case that the signal is divided instead of being multiplied by two? The answer to this question is that scaling factor depends on the direction of the signal. When RHR0 signal was travelling from Master Protocol to REDIS service and was passing the place where signals are scaled the signal was multiplied by scaling factor. On the other hand when WSR3 signal was travelling from REDIS service to Master Protocol and was passing the same signal scaling place the signal was divided by scaling factor.

Now let us analyze how "math_expression" and "source_math_expression" are applied to WSR5 signal. To get a better insight let us look how signals are transmitted and transformed inside WCC Lite and when mathematical expressions are applied.



Let us analyze the diagram above. As we can see all basic mathematical operations (such as add, multiply, etc.) are performed inside a Master protocol service. When signals are transmitted between protocols they travel through REDIS service. The period of existence of a signal inside the REDIS service can be divided into four stages. They can be denoted by their endings, namely: "rout", "out", "in" and "rin". At "out" and "rin" stages signal values can be seen through certain interfaces that is why they are displayed in a purple color with blue eyes on them. At "out" stage a signal is displayed on WCC Lite web-interface, at "rin" stage signal value can be seen through Vinci application. As one could notice "math_expression" is applied before "out" stage and "source_math_expression" is performed before "rin" stage.

However in our particular example we did not configure any Slave device. In this situation signal transportation inside REDIS service can be depicted as following:



Let us return to our example and let us see what are the values of WSR5 signal in WCC Lite web-interface and Vinci Slave simulation.

IMPORTED SIGNALS

Device	Signal	Value	Units	State	Attributes	Time
<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>
Master Protocol	Read Holding Register 4	10				2023-07-27 15:51:16.56
Master Protocol	Write Single Register 5	10			cot=10	2023-07-27 15:51:17.40

Protocol:

Modbus TCP

Mode:

Slave (Server)

STOP

IP:

192.168.1.2

Port:

502


Settings

Console

Statistic

Slave	Function	Address	Value	FormattedValue	Name
1	3	4	10	10	Register4
1	3	5	2		

The diagram below explains how these values were calculated.



Extra functions

Several functions are defined make tag operations possible:

- `TagValue(key)` - returns last known value of tag identified by redis key;
- `TagFlag(key)` - returns 1 if tag flag exists. Name format is: "key flag". For example to check if tag is non topical, name would be "tag/19xxxxxxx/x/x nt";
- `TagAttribute(key)` - similar to TagFlag, but returns a numeric value of a tag attribute;
- `TagTime(key)` - returns UNIX timestamp in milliseconds of a last know tag value.