

4.1 Status indication

Name	Description
STATUS	<ul style="list-style-type: none">● On (green) System is powered on● blinking (blue) Blinking in heartbeat pattern. Blinking is more intense when CPU load is high.● On (red) Fault (if configured)○ Off System is not powered
RELAY	<ul style="list-style-type: none">● On (green) Relay is activated (COM connected to NO)○ Off Relay is deactivated (COM connected to NC)
RX1/TX 1	<ul style="list-style-type: none">● On (yellow) PORT1 data TX● On (green) PORT1 data RX○ Off No activity on PORT1
RX1/TX 2	<ul style="list-style-type: none">● On (yellow) PORT2 data TX● On (green) PORT2 data RX○ Off No activity on PORT2
ETH 0	<ul style="list-style-type: none">● On (green) ETH0 LINK/Activity○ Off ETH0 not linked/inactive
ETH 1	<ul style="list-style-type: none">● On (green) ETH1 LINK/Activity○ Off ETH1 not linked/inactive
WLAN	<ul style="list-style-type: none">● On (blue) Wi-fi enabled● Blinking (blue) Connected○ Off Wi-fi disabled
GSM	<ul style="list-style-type: none">● Blinking (yellow) Registered to network○ Off Not registered to network● On (green) GSM signal level is over -65dBm● On (green) GSM signal level is over -85dBm● On (green) GSM signal level is lower than -85dBm



Figure 1: Front panel status indication

©Revision #1

★Created 20 December 2022 11:56:54 by Gabriele

✎Updated 20 December 2022 12:04:16 by Gabriele