

# 4.1 Status indication

Name	Description
STATUS	<ul style="list-style-type: none"><li>● On (green) System is powered on</li><li>● blinking (blue) Blinking in heartbeat pattern. Blinking is more intense when CPU load is high.</li><li>● On (red) Fault (if configured)</li><li>○ Off System is not powered</li></ul>
RELAY	<ul style="list-style-type: none"><li>● On (green) Relay is activated (COM connected to NO)</li><li>○ Off Relay is deactivated (COM connected to NC)</li></ul>
RX1/TX 1	<ul style="list-style-type: none"><li>● On (yellow) PORT1 data TX</li><li>● On (green) PORT1 data RX</li><li>○ Off No activity on PORT1</li></ul>
RX1/TX 2	<ul style="list-style-type: none"><li>● On (yellow) PORT2 data TX</li><li>● On (green) PORT2 data RX</li><li>○ Off No activity on PORT2</li></ul>
ETH 0	<ul style="list-style-type: none"><li>● On (green) ETH0 LINK/Activity</li><li>○ Off ETH0 not linked/inactive</li></ul>
ETH 1	<ul style="list-style-type: none"><li>● On (green) ETH1 LINK/Activity</li><li>○ Off ETH1 not linked/inactive</li></ul>
WLAN	<ul style="list-style-type: none"><li>● On (blue) Wi-fi enabled</li><li>● Blinking (blue) Connected</li><li>○ Off Wi-fi disabled</li></ul>
GSM	<ul style="list-style-type: none"><li>● Blinking (yellow) Registered to network</li><li>○ Off Not registered to network</li><li>● On (green) GSM signal level is over -65dBm</li><li>● On (green) GSM signal level is over -85dBm</li><li>● On (green) GSM signal level is lower than -85dBm</li></ul>



Figure 1: Front panel status indication