

## 4.1 Status indication

| Name     | Description  |
|----------|--|
| STATUS   | <ul style="list-style-type: none"><li>● On (green) System is powered on</li><li>● blinking (blue) Blinking in heartbeat pattern. Blinking is more intense when CPU load is high.</li><li>● On (red) Fault (if configured)</li><li>○ Off System is not powered</li></ul>                                |
| RELAY    | <ul style="list-style-type: none"><li>● On (green) Relay is activated (COM connected to NO)</li><li>○ Off Relay is deactivated (COM connected to NC)</li></ul>   |
| RX1/TX 1 | <ul style="list-style-type: none"><li>● On (yellow) PORT1 data TX</li><li>● On (green) PORT1 data RX</li><li>○ Off No activity on PORT1</li></ul>  |
| RX1/TX 2 | <ul style="list-style-type: none"><li>● On (yellow) PORT2 data TX</li><li>● On (green) PORT2 data RX</li><li>○ Off No activity on PORT2</li></ul>  |
| ETH 0    | <ul style="list-style-type: none"><li>● On (green) ETH0 LINK/Activity</li><li>○ Off ETH0 not linked/inactive</li></ul>   |
| ETH 1    | <ul style="list-style-type: none"><li>● On (green) ETH1 LINK/Activity</li><li>○ Off ETH1 not linked/inactive</li></ul>   |
| WLAN     | <ul style="list-style-type: none"><li>● On (blue) Wi-fi enabled</li><li>● Blinking (blue) Connected</li><li>○ Off Wi-fi disabled</li></ul>   |
| GSM      | <ul style="list-style-type: none"><li>● Blinking (yellow) Registered to network</li><li>○ Off Not registered to network</li><li>● On (green) GSM signal level is over -65dBm</li><li>● On (green) GSM signal level is over -85dBm</li><li>● On (green) GSM signal level is lower than -85dBm</li></ul> |



Figure 1: Front panel status indication

©Revision #1

★Created 11 January 2024 09:21:54 by Gabriele

✎Updated 11 January 2024 09:38:18 by Gabriele