

16.9 SOLPLUS

Overview

Solplus protocol is used to download inverter data from Solplus inverters using an HTTP client.

Configuration

Solplus parameters for *Device* tab

Parameter	Type	Description	Required	Default value (when not specified)	Range	
					Min	Max
name	string	User-friendly device name	Yes			
description	string	Description of a device	No			
device_alias	string	Alphanumeric string to identify a device	Yes			
enable	boolean	Enabling/disabling of a device	No	1	0	1
protocol	string	Protocol to be used.	Yes		Solplus	
scan_rate_ms	integer	All reads and writes will be executed within the timeframe in milliseconds	No	10000		
poll_delay_ms	integer	Minimum time delay in milliseconds to wait before sending any data on port.	No	200		
timeout_ms	integer	Timeout of waiting for incoming requests in milliseconds	No	2500	0	60000
url	string	HTTP server location URL	Yes			

Solplus parameters for *Signals* tab

Parameter	Type	Description	Required	Default value (when not specified)	Range	
					Min	Max
signal_name	string	User-friendly signal name	Yes			
device_alias	string	Device alias from a Devices tab	Yes			
signal_alias	string	Unique alphanumeric name of the signal to be used	Yes			

enable	boolean	Enabling/disabling of an individual signal	No	1	0	1
log	integer	Enable logging in the event log	No	0		
number_type	string	Type of a number (FLOAT, DOUBLE, DIGITAL, etc.)	Yes			
job_todo	string	Tag job as single or multiple comma-separated OBIS codes	Yes			
tag_job_todo	string	Tag sub job	Yes			
pulse_short_time_ms	integer	The time interval for a short output pulse to stay active	No	0		
pulse_long_time_ms	integer	The time interval for a long output pulse to stay active	No	0		

🔄Revision #2

★Created 26 January 2024 13:13:08 by Gabriele

✎Updated 13 June 2024 13:29:04 by Gabriele