

4 WCC Lite status indication and control

- 4.1 Status indication
- 4.2 Reset button

4.1 Status indication

| Name | Description |
|----------|--|
| STATUS | <ul style="list-style-type: none"> ● On (green) System is powered on ● blinking (blue) Blinking in heartbeat pattern. Blinking is more intense when CPU load is high. ● On (red) Fault (if configured) ○ Off System is not powered |
| RELAY | <ul style="list-style-type: none"> ● On (green) Relay is activated (COM connected to NO) ○ Off Relay is deactivated (COM connected to NC) |
| RX1/TX 1 | <ul style="list-style-type: none"> ● On (yellow) PORT1 data TX ● On (green) PORT1 data RX ○ Off No activity on PORT1 |
| RX1/TX 2 | <ul style="list-style-type: none"> ● On (yellow) PORT2 data TX ● On (green) PORT2 data RX ○ Off No activity on PORT2 |
| ETH 0 | <ul style="list-style-type: none"> ● On (green) ETH0 LINK/Activity ○ Off ETH0 not linked/inactive |
| ETH 1 | <ul style="list-style-type: none"> ● On (green) ETH1 LINK/Activity ○ Off ETH1 not linked/inactive |
| WLAN | <ul style="list-style-type: none"> ● On (blue) Wi-fi enabled ● Blinking (blue) Connected ○ Off Wi-fi disabled |
| GSM | <ul style="list-style-type: none"> ● Blinking (yellow) Registered to network ○ Off Not registered to network ● On (green) GSM signal level is over -65dBm ● On (green) GSM signal level is over -85dBm ● On (green) GSM signal level is lower than -85dBm |



Figure 1: Front panel status indication

4.2 Reset button

The reset button is located on the front panel of WCC Lite, to access it, remove a transparent front panel cover. Different time lengths of button pressing call for different behaviour.

| Pressing time | Description | Indication |
|------------------|---------------------------|------------------------------------|
| Short Press | System reboot | The red STATUS LED starts blinking |
| Long press (>3s) | Reset to factory settings | Red STATUS LED turns on |