

# 16.1 At command

## Overview

At command protocol is used for communications with AT Commands.

## Configuration

At command parameters for the *Device* tab

Parameter	Type	Description	Required	Default value (when not specified)	Range	
					Min	Max
name	string	User-friendly device name	Yes			
description	string	Description of a device	No			
device_alias	string	Alphanumeric string to identify a device	Yes			
enable	boolean	Enabling/disabling of a device	No	1	0	1
protocol	string	Protocol to be used.	Yes		at command	
device	string	Communication port	Yes		PORT1	PORT2
baudrate	integer	Communication speed (bauds/s)	No	9600	300, 600, 1200, 2400, 4800, 9600, 19200, 38400, 57600, 115200	
databits	integer	Data bit count for communication	No	8	6	9
stopbits	integer	Stop bit count for communication	No	1	1	2
parity	string	Communication parity option	No	none	none, even, odd	
flowcontrol	string	Communication device flow control option.	No	none	none	
timeout_ms	integer	Timeout of waiting for incoming requests in milliseconds	Yes		0	60000
serial_close_delay	integer	Delay before closing serial port	No	400		

At command parameters for the *Signals* tab

Parameter	Type	Description	Required	Default value (when not specified)	Range	
					Min	Max

signal_name	string	User-friendly signal name	Yes			
device_alias	string	Device alias from a Devices tab	Yes			
signal_alias	string	Unique alphanumeric name of the signal to be used	Yes			
enable	boolean	Enabling/disabling of an individual signal	No	1	0	1
log	integer	Enable logging in the event log	No	0		
number_type	string	Type of a number (FLOAT, DOUBLE, DIGITAL, etc.)	Yes			
job_todo	string	Tag job as single or multiple comma-separated OBIS codes	Yes			
tag_job_todo	string	Tag sub job	Yes			

🕒Revision #2  
★Created 26 January 2024 13:13:07 by Gabriele  
✎Updated 13 June 2024 13:14:15 by Gabriele