

# 22 COMLYNX

## Overview

Comlynx protocol is used to communicate with Comlynx inverters over serial communication.

### Comlynx parameters for *Device* tab:

| Parameter     | Type    | Description  | Required | Default value<br>(when not specified) | Range   |       |
|---------------|---------|--|----------|---------------------------------------|---|-------|
|               |         |  |          |                                       | Min   | Max   |
| name          | string  | User-friendly device name  | Yes      |                                       |   |       |
| description   | string  | Description of the device  | No       |                                       |   |       |
| device_alias  | string  | Device alias to be used in configuration   | Yes      |                                       |   |       |
| enable        | boolean | Enabling/disabling of a device   | No       | 1                                     | 0   | 1     |
| protocol      | string  | Selection of protocol  | Yes      |                                       | Comlynx   |       |
| address       | integer | Device address   | No       | 1                                     |   |       |
| subnet        | integer | Subnet address   | No       | 0                                     |   |       |
| network       | integer | Network address  | No       | 0                                     |   |       |
| device        | string  | Communication port   | Yes      |                                       | PORT1   | PORT2 |
| baudrate      | integer | Communication speed, bauds/s   | No       | 19200                                 | 300, 600, 1200, 2400, 4800, 9600, 19200, 38400, 57600, 115200 |       |
| databits      | integer | Data bit count for communication   | No       | 8                                     | 6   | 9     |
| stopbits      | integer | Stop bit count for communication   | No       | 1                                     | 1   | 2     |
| parity        | string  | Communication parity option ("none"/"even"/"odd")  | No       | none                                  |   |       |
| flowcontrol   | string  | Communication device flow control option. (Default: (case-sensitive): "none")                        | No       | none                                  |   |       |
| scan_rate_ms  | integer | If provided and positive all reads and writes will be executed within the timeframe in milliseconds. | No       | 10000                                 |   |       |
| poll_delay_ms | integer | Minimum time delay in milliseconds to wait before sending any data on port.                          | No       | 200                                   |   |       |
| timeout_ms    | integer | Timeout in milliseconds  | Yes      |                                       | 0   | 60000 |

## Comlynx parameters for *Signals* tab:

| Parameter           | Type    | Description   | Required | Default value<br>(when not specified) | Range |     |
|---------------------|---------|---|----------|---------------------------------------|-------|-----|
|                     |         |   |          |                                       | Min   | Max |
| signal_name         | string  | User-friendly device name                           | Yes      |                                       |       |     |
| device_alias        | string  | Device alias from a Devices tab                     | Yes      |                                       |       |     |
| signal_alias        | string  | Unique alphanumeric name of the signal to be used   | Yes      |                                       |       |     |
| enable              | boolean | Enabling/disabling of an individual signal          | No       | 1                                     | 0     | 1   |
| log                 | integer | Allow signal to be logged.                          | No       | 0                                     |       |     |
| job_todo            | boolean | Define tag-function                                 | Yes      |                                       |       |     |
| tag_job_todo        | string  | Define tag action that depends on tag function      | Yes      |                                       |       |     |
| number_type         | integer | Type of a number (FLOAT, DOUBLE, DIGITAL, etc.)     | Yes      |                                       |       |     |
| pulse_short_time_ms | integer | Time interval for short output pulse to stay active | No       | 0                                     |       |     |
| pulse_long_time_ms  | integer | Time interval for long output pulse to stay active  | No       | 0                                     |       |     |

🔄Revision #3

★Created 29 November 2021 12:28:32

✎Updated 28 December 2021 13:19:14